

Meridium APM AHI

V3.6.1.6.0



Meridium APM AHI

V3.6.1.6.0

© 2017 General Electric Company.

GE, the GE Monogram, and Predix are either registered trademarks or trademarks of General Electric Company. All other trademarks are the property of their respective owners.

This document may contain Confidential/Proprietary information of General Electric Company and/or its suppliers or vendors. Distribution or reproduction is prohibited without permission.

THIS DOCUMENT AND ITS CONTENTS ARE PROVIDED "AS IS," WITH NO REPRESENTATION OR WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF DESIGN, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. ALL OTHER LIABILITY ARISING FROM RELIANCE UPON ANY INFORMATION CONTAINED HEREIN IS EXPRESSLY DISCLAIMED.

Access to and use of the software described in this document is conditioned on acceptance of the End User License Agreement and compliance with its terms.

About This Document

This file is provided so that you can easily print this section of the Meridium APM Help system.

You should, however, use the Help system instead of a printed document. This is because the Help system provides hyperlinks that will assist you in easily locating the related instructions that you need. Such links are not available in a print document format.

The Meridium APM Help system can be accessed within Meridium APM itself or via the Meridium APM Documentation Website (<u>https://www.me</u>-ridium.com/secure/documentation/WebHelp/Home.htm).

Note: If you do not have access to the Meridium APM Documentation Website, contact GE Global Support (<u>https://www.ge.com/digital/asset-performance-management</u>).

Table of Contents

Meridium APM AHI	1
Copyright and Legal	. 2
About This Document	3
Table of Contents	. 4
Overview of Asset Health Manager	. 9
AHM System Requirements	.10
Assumptions Made in the AHM Documentation	12
AHM Data Model	.13
Health Indicator Mapping Records	.16
The Structure of the Tree in the AHI Explorer Pane	.17
Example Used in the AHM Documentation	.19
Accessing the AHM Start Page	.21
Overview of the AHM Start Page	.22
Health Indicator Filter Section	.23
Links Section	.24
Health Indicators in Alert Section	.25
First-Time Deployment Workflow	.27
Upgrade or Update Asset Health Manager to V3.6.1.6.0	30
Modifying the File Meridium.AHI.Service.exe.config	41
MI AHI Administrator	.43
MI AHI User	45
AHM User Workflow	.47
About Accessing the Asset Health Manager Page	.48
Accessing the Asset Health Manager Page for a Single Piece of Equipment	.49
Accessing the Asset Health Manager Page for All Equipment Belonging to a Loca- tion	.52
Accessing the Asset Health Manager Page for a Single Piece of Equipment in Alert Condition	.55
Accessing the Asset Health Manager Page for a Location With at Least One Piece of Equipment in Alert Condition	.56

Aspects of the Asset Health Manager Page	58
Refreshing the Asset Health Manager Page	59
Common Tasks Menu	60
Associated Pages Menu	61
About the Health Indicator Explorer Pane	62
Sorting Nodes in the Health Indicator Explorer Pane	65
Accessing the Manage Filters Window	66
Aspects of the Manage Filters Window	67
Applying Filters	68
Clearing Filters	69
Creating Custom Filters	70
Deleting Custom Filters	71
About the Tabs	72
About the Summary Tab	75
About the Gauges	77
Interpreting Gauges Representing Numeric Measurement Locations	78
Interpreting Gauges Representing Character Measurement Locations	80
Interpreting Gauges Representing KPIs Where Low Values are Good	82
Interpreting Gauges Representing KPIs Where High Values are Good	84
Interpreting Gauges Representing Numeric Xi Tags	
Interpreting Gauges Representing Character Xi Tags	89
Policies Tab	91
Recommendations Tab	92
Details Tab	
About the Trend Tab	95
About the Graph	97
About the Data Range Criteria	101
About the Zoom Buttons	104
Source Tab	106
Stored Data	

Snapshot Tab	108
About the Events Tab	109
Grid	110
Filter Section	112
Viewing the Event Tab in Full Screen Mode	115
Expanding and Collapsing the Filter Section	117
Filtering the Grid By Event Severity	118
Filtering the Grid By Event Type	121
Filtering Event Data by Date	124
About Health Indicator Statuses	127
Statuses of Health Indicators Based on Numeric Measurement Locations	128
Statuses of Health Indicators Based on Character Measurement Locations	130
Statuses of Health Indicators Based on KPIs Where Low Values are Good	131
Statuses of Health Indicators Based on KPIs Where High Values are Good	132
Statuses of Health Indicators Based on Numeric Xi Tags	133
Statuses of Health Indicators Based on Character Xi Tags	135
Acknowledging a Single Health Indicator Record's Status	136
Acknowledging Multiple Health Indicator Records' Statuses	138
Revoking the Acknowledgement of a Health Indicator Record's Status	140
Creating Health Indicator Records via the Asset Health Manager Page	141
Creating Health Indicator Records from the AHM Start Page	144
About Creating Health Indicator Records via Policy Manager	150
Changing the Name or Description of a Health Indicator Record	151
Creating a Recommendation Record Based Upon a Single Health Indicator	152
Creating a Recommendation Record Based Upon Multiple Health Indicators	153
Values Mapped to Meridium General Recommendation Records	156
Viewing Existing Recommendation Records	158
Activating an Inactive Policy Instance	159
Deleting a Health Indicator Record	160
About Modifying Limit Values in Health Indicator Records	161

AHM Catalog Folder Structure	163
Dashboards Folder	
Queries Folder	165
Dashboard Queries Folder	
Event Mapping	
Health Indicator	
Health Indicator Mapping	
Event Mappings Overview	
Accessing the Event Mappings Window	175
Aspects of the Event Mappings Window	
Source Event Family Pane	
Mappings Pane	
Accessing the Event Mappings Page	
Aspects of the Event Mappings Page	
Creating New Event Mapping Records	
Modifying Existing Event Mappings	
Deleting Event Mapping Records	
Calibration Subfamilies	194
Inspection Families	
Checklists Subfamilies	
Policy Event Family	
Production Event Family	
Work History Family	
System Code Tables Used by AHM	204
Parameters for the AHM URLs	
Examples of the AHM URLs	
Event Mapping	
Event Severity	
Primary Source Record	
Secondary Source Record	210

Overview of Asset Health Manager

The Meridium APM Asset Health Manager (AHM) module provides tools that help you evaluate the overall health of equipment. Using AHM, you can view a graphical representation of a piece of equipment's health and then make decisions about what action to take in order to mitigate risk, if necessary.

In AHM, a piece of equipment's health is determined by data that exists in various records in the Meridium APM database. You can determine which records contain information that indicate the piece of equipment's health and then create a Health Indicator record that is linked to those records.

In the baseline AHM database, you can use AHM to view a graphical representation of data in the following types of records:

- Measurement Location records and their linked Reading records
- KPI records and their linked KPI Measurement records
- Xi Tag records and their linked Xi Reading records
- Health Indicator records and their linked Health Indicator Value records

AHM System Requirements

AHM is a feature that can be used to its complete potential only when it is integrated with the following modules:

- Operator Rounds
- Metrics and Scorecards
- Asset Strategy Management
- Process Data Integration

Note: To integrate AHM with these modules, you will also need to complete the installation and configuration tasks that are required for them.

The *Meridium APM Framework Tools* license and the licenses for the modules that you want to use with AHM are required to take advantage of AHM functionality.

In addition, your system must contain the basic Meridium APM architecture and additional machines and components for PDI users, which are described in the *Additional Requirements for PDI Users* section in this topic.


When you install the Meridium APM Application Server, the Meridium AHM Service is installed automatically. After you have installed and configured the basic system architecture, you will need to perform some configuration tasks specifically for AHM. In order for the AHM Service to function as described within this documentation, you must first modify the file *Meridium.AHI.Service.exe.config*. After you configure the settings in this file, the AHM Service will allow the <u>Health Indicator status values</u> to be updated automatically.

Additional Requirements

If you want to use AHM with Process Data Integration and Policy Manager, in addition to the basic Meridium APM system architecture, your system must also contain the following additional components:

- **Meridium APM Process Data Integration Server**: A machine on which the Meridium APM Process Data Integration Service is installed. This machine is required by the AHM module only if you want to create Health Indicator records from Xi Tag records.
- **Meridium APM Policy Execution Server**: A machine on which the Meridium APM Policies Execution Service is installed. This machine is required by the AHM module only if you want to use Policy Manager to modify health indicators.

The following image provides an illustration of the architecture components that are required for deploying AHM, assuming that you are also deploying Process Data Integration and Policy Manager.



Assumptions Made in the AHM Documentation

The AHM documentation assumes that:

- An Equipment record already exists to identify the piece of equipment whose health you want to evaluate.
- The Equipment record is linked to a Functional Location record representing the location in which it is installed, and that Functional Location record is linked to another Functional Location record representing the higher-level location to which it belongs.
- You want to access AHM from *outside* of Asset Strategy Management.
- The AHM Service is installed and running at all times on the Meridium APM Application Server.
- You will use the records listed in the table below as the primary and secondary source records to new Health Indicator records, and these records already exist.

Primary source record	Linked to secondary source record
Measurement Location	Reading
Xi Tag	Xi Reading
KPI	KPI Measurement
Health Indicator (created via Policy Manager)	Health Indicator Value


• The Equipment record is linked to the associated primary source records.

AHM Data Model

Like all Meridium APM modules, the Meridium APM Asset Health Manager feature consists of entity families, relationship families, and business rules. The **Asset Health Manager** page in AHM provides you with a custom view of Health Indicator records that exist in the database. This page also facilitates the creation of new records and displays data that will inform decisions that a user will make based upon the health of equipment.

When attempting to understand and make use of the Meridium APM AHM functionality, it can be helpful to visualize the AHM data model. Because you should already be familiar with the concept of records and viewing records in the Meridium APM Record Manager, during your introduction to AHM, it may be useful to remember that AHM is simply a customized view of individual records.

The following diagram illustrates how families are related to one another within the AHM data model. In the following image, boxes represent entity families, and arrows represent relationship families that are configured in the baseline database.



Note that the *Primary Source* box in this image does not represent a family with the caption *Primary Source*. Instead, it represents a family containing a record that will be linked to a Health Indicator record. In the Meridium APM baseline database, Health Indicator records can be linked to the following types of records through the Health Indicator Has Source relationship:

- Measurement Location
- Xi Tag
- KPI
- Health Indicator

If desired, you can configure this relationship definition to include other families as successors to the Health Indicator family.

Health Indicator Mapping Records

Health Indicator Mapping records are used to determine how values will be mapped from primary source records (e.g., Measurement Location, Xi Tag) to the Health Indicator records that they are used to create. They are also used to help determine the status of the Health Indicator record after it exists and how data will be displayed on the <u>Asset Health Manager page</u>.

The following table lists the Health Indicator Mapping records that are provided in the baseline database and a description of which types of values each record maps to Health Indicator records.

Record ID	Description
Character mapping for XI Tag ~ Character	Used to map values from Xi Tag records that accept character values.
Health Indicator ~ Self Map- ping ~ Numeric	Used to map values from Health Indicator records that accept numeric values and are created via the Policy Manager module.
KPI A - High Is Good ~ Numeric	Used to map values from KPI records where high values are good, (e.g., profit).
KPI B - Low Is Good ~ Numeric	Used to map values from KPI records where low values are good, (e.g., MTBF).
Measurement Location ~ Character Mapping for Measurement Location ~ Character	Used to map values from Measurement Location records that accept character values.
Measurement Location ~ Numeric Mapping for Meas- urement Location ~ Numeric	Used to map values from Measurement Location records that accept numeric values.
Numeric mapping for Xi Tag ~ Numeric	Used to map values from Xi Tag records that accept numeric values.

If you are using the standard <u>AHM workflow</u>, you do not need to create Health Indicator Mapping records. The baseline records provide the functionality that you need to complete the AHM workflow.

The Structure of the Tree in the AHI Explorer Pane


If you are using the Meridium APM product according to the Meridium APM Best Practice:

- *Equipment* records will store information about pieces of equipment.
- *Functional Location* records will store information about locations.
- Functional Location records will be linked together, where the predecessor Functional Location record represents a higher-level location in your location hierarchy.

The AHM module is configured assuming your data is structured in this way. Specifically, several baseline Hierarchy Item Definition and Hierarchy Item Child Definition records are provided in the database to support this assumption.


As a result of the values in these baseline configuration records, in the tree on the **Asset Health Manager** page, you can view Functional Location record representing the higherlevel location as the root node, the Functional Location record representing the lowerlevel location as a subnode of the root node, and the Equipment record as a subnode of the lower-level location node.

For example, suppose that your database contains the following records and links, where the squares represent records, and the family caption is listed in parentheses.



Based on this example, you would want the tree to be structured like the one shown in the following image.

The Structure of the Tree in the AHI Explorer Pane




You could then add Health Indicator records that would be linked to the *Water Heater* Equipment record.


Example Used in the AHM Documentation

Throughout this documentation, we use an example of how you might use AHM to assess the health of a water heater. In this illustration, a house (the unit) contains a plumbing system, which contains a water heater. Throughout this documentation, we assume that:

- An Equipment record exists to define the water heater.
- The Equipment record is linked to a predecessor Functional Location record representing the plumbing system.
- The Functional Location record representing the plumbing system is linked to a predecessor Functional Location record representing the house.
- The Equipment record is linked to multiple Measurement Location records and Xi Tag records (primary source records).
- Each Measurement Location record is linked to multiple Reading records (secondary source records) that contain reading values.
- Each Xi Tag record is linked to multiple Xi Reading records (secondary source records) that contain reading values.
- A KPI record (primary source) exists to track information about the water heater. In addition, this KPI record is linked to at least one KPI Measurement record (secondary source record).

More specifically, the example presented throughout this documentation assumes that the records and links exist as illustrated in the following diagram.





Accessing the AHM Start Page

The <u>AHM Start Page</u> provides access to the features associated with the Asset Health Manager module.

To access the AHM Start Page:

• On the Meridium APM Framework main menu, click **Go To**, point to **APM Found**ation, and then click **Asset Health Manager**.

The **<u>AHM Start Page</u>** appears.

S Meridium APM Framework - Dashboard - AHM Start Page		x
<u>F</u> ile <u>E</u> dit <u>G</u> o To <u>T</u> ools <u>H</u> elp		
📚 Back 👻 🦻 Forward 👻 👌 Refresh 🐐 My Start Page 👻 隆 New 🔎 So	Search 🚞 Catalog 🧑 Query - 🛅 Report - 🕼 Graph - 🧐 Dataset - 📟 Dashboard -	
🔆 AHM Start Page	2 C	>
Health Indicator Filter	Health Indicators in Alert	
Location ID	Alert Level 💠 Superior Location 💠 Equipment Technical Number 💠 Health Indicator	1
Time Range	Alert MRD-ROA-REFN-RF097-ZL0003-097 PDC00035V-097 AHM test dashboard AHI record	
Past Year		
Apply		
Links		
Search Equipment to View Asset Health		
Search Functional Locations to View Asset Health		
Create New Health Indicators for Assets		
	< •	1

Overview of the AHM Start Page

The **Dashboard - AHM Start Page** is different from other module start pages in the Meridium APM Framework in that it displays the contents of the following <u>dashboard</u> <u>Catalog item</u> and its <u>underlying queries</u> on the **Dashboard** page: \\Public\Meridium\Modules\AHI\Dashboards\AHM Start Page. Throughout the documentation, we refer to the **Dashboard - AHM Start Page** simply as the *AHM Start Page*.

Service Meridium APM Framework - Dashboard - AHM Start Page	
<u>F</u> ile <u>E</u> dit <u>G</u> o To <u>T</u> ools <u>H</u> elp	
😵 Back 👻 🛞 Forward 👻 🔗 Refresh 🐐 My Start Page 👻 🎉 New 🔑 S	Search ≽ Catalog 🔞 Query + 🗓 Report + 🕼 Graph + 🍕 Dataset + 📾 Dashboard +
💮 AHM Start Page	
Health Indicator Filter	Health Indicators in Alert
Location ID	Alert Level Superior Location Equipment Technical Number Health Indicator
Time Range	Alert MRD-ROA-REFN-RF097-ZL0003-097 PDC0003SV-097 AHM test dashboard AHI record
Past Year	
Apply	
Links	
Search Equipment to View Asset Health	
Search Functional Locations to View Asset Health	
Create New Health Indicators for Assets	
	<pre>// // // // // // // // // // // // //</pre>

The AHM Start Page displays the following sections by default:

- Health Indicator Filter
- Links
- Health Indicators in Alert

Health Indicator Filter Section

The **Health Indicator Filter** section is a configured **Content Filter** dashboard section that contains a list and text box that are used to filter the data that is displayed in the <u>Health</u> <u>Indicators in Alert section</u> on the dashboard.

Health Indicator Filter	
Location ID ROA	
Time Range	
Past Quarter	-
	Apply

The Health Indicator Filter section contains the following items:

- Location ID text box: Lets you specify the value that exists in the Superior Function Location field in the Functional Location record that is linked to the Equipment record whose Health Indicator records whose data you want to see in the <u>Health Indicators in Alert section</u>. Using our <u>AHM example</u>, you would type the value in the Superior Function Location field in the *Plumbing System* Functional Location record.
- Time Range list: Determines the period of time associated with the Last Reading Date value in the Health Indicator records that you want to see in the <u>Health Indicators in Alert section</u>. This list contains the following values:
 - Past Day: Causes the Health Indicators in Alert section to display Health Indicator records with today's or yesterday's date in the Last Reading Date field.
 - Past Week: Causes the Health Indicators in Alert section to display Health Indicator records with today's or the one of the past seven days in the Last Reading Date field.
 - Past Month: Causes the Health Indicators in Alert section to display Health Indicator records with today's or the one of the past thirty days in the Last Reading Date field. This value is selected by default.
 - Past Quarter: Causes the Health Indicators in Alert section to display Health Indicator records with today's or the one of the past 90 days in the Last Reading Date field.
 - Past Year: Causes the Health Indicators in Alert section to display Health Indicator records with today's or the one of the past 365 days in the Last Reading Date field.
- Apply button: Applies the filter (your selections in the Location ID text box and Time Range list) to the content that is displayed in the Health Indicators in Alert section.

Links Section

The **Links** section on the <u>AHM Start Page</u> is a configured **Hyperlinks** dashboard section that contains various links that provide navigation to areas in the Meridium APM Framework.

Links
Search Equipment to View Asset Health
Search Functional Locations to View Asset Health
Create New Health Indicators for Assets

The Links section contains the following links:

- Search Equipment to View Asset Health: Displays the Find Items window, where you can search for Equipment records whose associated Health Indicator record(s) you want to view on the Asset Health Manager page. If you access the Asset Health Manager page using this link, the top node of the tree will represent the Equipment record, not the Functional Location record representing the location to which it belongs.
- <u>Search Functional Locations to View Asset Health</u>: Displays the Find Items window, where you can search for Functional Location records that are associated with (i.e., linked directly or indirectly to) the Equipment record whose Health Indicator record(s) you want to view on the <u>Asset Health Manager page</u>. If you access the **Asset Health Manager** page using this link, the top node of the tree will represent the selected Functional Location record.
- <u>Create New Health Indicators for Assets</u>: Displays the Mass Health Indicator Builder, which you can use to create new Health Indicator records.

Health Indicators in Alert Section

The **Health Indicators in Alert Section** is a configured **List - Query Result** dashboard section that contains a grid that displays information according to your selections in the <u>Health Indicator Filter section</u>. Specifically, this section displays information about Health Indicator records whose Alert Level field contains the value 1 or 2 (where 1 represents *Alert* and 2 represents *Warning*) and the Equipment and Functional Location records that are linked to those Health Indicator records (directly or indirectly).

The following image shows an example of the **Health Indicators in Alert** section as it appears using the AHM example data.


Health Indicators in Alert				~			
Alert Level	\$	Superior Location	\$	Equipment Technical Number	٥	Health Indicator	\$
Alert		MRD-ROA-REFN-RF097-ZL0003-097		PDC00035V-097		AHM test dashboard AHI record	
•			11	1			•

Each row in the grid represents a separate Health Indicator record that meets *Alert* or *Warning* status criteria and the criteria that you defined in the **Health Indicator Filter** section.


The grid contains the following columns of information:

- Alert Level: Identifies the status of the health indicator. The background color of these cells corresponds to the status of the Health Indicator record.
- Superior Location: Displays the value in the Superior Function Location field in the Functional Location record that is linked to Equipment record to which the Health Indicator record is linked. The values in this column appear as hyperlinks, which you can click to open the <u>Asset Health Manager page</u> and display that Functional Location record as the root node in the tree.

Using our <u>AHM example data</u>, this column displays the value *Plumbing System*, which appears in the Superior Function Location field in the lower-level Functional Location record *PL-101*. When you click the link, the tree on the **Asset Health Manager** page displays the *Plumbing System* node as the root node.




You would need to expand the tree fully to see the Equipment node and the Health Indicator nodes.



• Equipment Technical Number: The value in the Equipment Technical number field in the Equipment record that is linked to the Health Indicator record. The values in this column appear as hyperlinks, which you can click to open the <u>Asset Health</u> <u>Manager page</u> and display that Equipment record as the root node in the tree.

Using our <u>AHM example data</u>, this column displays the value *WH101*, which appears in the Equipment Technical Number field in the *Water Heater* Equipment record. When you click the link, the tree on the **Asset Health Manager** page displays the *Water Heater* node as the root node.



- Health Indicator: The value in the Name field in the Health Indicator record.
- Last Reading Date: The value in the Last Reading Date field in the Health Indicator record.

First-Time Deployment Workflow

Deploying and configuring Asset Health Manager (AHM) for the first time includes completing multiple steps, which are outlined in the table in this topic. The steps in this section of the documentation provide all the information that you need to deploy AHM within the basic Meridium APM system architecture.

The location where you will need to perform each step, (i.e., in the APM Framework application, in an administrative application, or on a server machine) is indicated in the **Location** cell in the table. Whether a step is required or optional is indicated in the **Required/Optional** cell. Steps are marked as *Required* if you must perform the step to take advantage of AHM functionality.

The person responsible for completing each task may vary within your organization. We recommend, however, that each step be performed in relatively the same order in which they are listed in the following table.

Ste- p	Task	Location	Required/Op- tional	Notes
1	<u>Specify settings in the file</u> <u>Meridi</u> - <u>um.AHI.Service.exe.config</u> .	Meridium APM Applic- ation Server, Meridium APM Pro- cess Data Integration Server, and Meridium APM Policy Execution Server	Required	Always required on the Applic- ation Server. Required on the Process Data Integ- ration Server only if you want to cre- ate Health Indicator records from Xi Tag records. Required on the Policy Exe- cution Server only if you want to use Policy Man- ager to modify health indicators.

First-Time Deployment Workflow

Ste- p	Task	Location	Required/Op- tional	Notes
2	Review the AHM data model to determine which rela- tionship definitions you will need to modify to include your custom equipment and location families.	Con- figuration Manager	Optional	This task is necessary only if you store equip- ment and loc- ation information in families other than the baseline Equipment and Func- tional Loca- tion families.
3	Assign Security Users to the <u>MI AHI Administrator</u> or <u>MI</u> <u>AHI User</u> Security Group.	Con- figuration Manager	Required	None
4	Determine the equipment whose overall health you want to evaluate, and make sure that an Equipment record and Functional Loca- tion record (representing the location in which the equip- ment is installed) exist in the database for this equipment. Also, make sure that the Func- tional Location record is linked to a predecessor Func- tional Location record.	APM Frame- work	Required	In the example used throughout this doc- umentation, the piece of equipment is the water heater.

Ste- p	Task	Location	Required/Op- tional	Notes
5	Determine which of the fol- lowing existing, primary source records provide an indication of the equipment's health:	APM Frame- work	Required	None
	 Measurement Location records: Created using Operator Rounds 			
	 KPI records: Created using Metrics and Score- cards 			
	 Xi Tag records: Created using Process Data Integration 			
	Health Indicator Value records: Created using Policy Manager.			
6	Create a new Health Indicator record for each primary source record that you chose in the previous step.	APM Frame- work	Required	None

Upgrade or Update Asset Health Manager to V3.6.1.6.0

The following table lists the step that is required to update or upgrade AHM to V3.6.1.6.0. This step assumes that you have completed the steps for upgrading the basic Meridium APM architecture.

Update from any version V3.6.1.0.0 through V3.6.1.5.0

This module will be updated to V3.6.1.6.0 automatically when you update the components in the basic Meridium APM system architecture. No additional steps are required.

Upgrade from any version V3.6.0.0.0 through V3.6.0.12.8

Ste- p	Task	Location	Required/Op- tional	Notes
1	Specify settings in the file Meridi- um.AHI.Service.exe.config.	Meridium APM Applic- ation Server -and- Meridium APM Pro- cess Data Integ- ration Server	Required	During the server upgrade pro- cess, a backup of your pre- viously used con- figuration file was cre- ated. You can use this pre-upgrade file as a ref- erence to modify the new baseline con- figuration file. You should <i>not</i> overwrite the baseline con- figuration file, as changes may have been made that are required for the service to work cor- rectly. After you modify the baseline

Ste- p	Task	Location	Required/Op- tional	Notes
				con- figuration file, you can delete the pre-upgrade con- figuration file.

Upgrade from any version V3.5.1.0.0 through V3.5.1.12.1

Ste- p	Task	Location	Required/Op- tional	Notes
1	Specify settings in the file Meridi- um.AHI.Service.exe.config.	Meridium APM Applic- ation Server -and- Meridium APM Pro- cess Data Integ- ration Server	Required	During the server upgrade pro- cess, a backup of your pre- viously used con- figuration file was cre- ated. You can use this pre-upgrade file as a ref- erence to modify the new baseline con- figuration file. You should <i>not</i> overwrite the baseline con- figuration file, as changes may have been made that are required for the service to work cor- rectly. After you modify the baseline

Ste- p	Task	Location	Required/Op- tional	Notes
				con- figuration file, you can delete the pre-upgrade con- figuration file.

Upgrade from any version V3.5.0 SP1 LP through V3.5.0.1.10.0

Ste- p	Task	Location	Required/Op- tional	Notes
1	Specify settings in the file <u>Meridi</u> - <u>um.AHI.Service.exe.config</u> .	Meridium APM Applic- ation Server -and- Meridium APM Pro- cess Data Integ- ration Server	Required	During the server upgrade process, a backup of your pre- viously used con- figuration file was cre- ated. You can use this pre- upgrade file as a ref- erence to modify the new baseline con- figuration file. You should <i>not</i> overwrite the baseline con- figuration file, You should <i>not</i> overwrite the baseline con- figuration file, as changes may have been made that are required for the service to work cor- rectly. After

Ste- p	Task	Location	Required/Op- tional	Notes
				you modify the baseline con- figuration file, you can delete the pre- upgrade con- figuration file.

Upgrade from any version V3.5.0 through V3.5.0.0.7.1

Ste- p	Task	Location	Required/Op- tional	Notes
1	Specify settings in the file <u>Meridi</u> - <u>um.AHI.Service.exe.config</u> .	Meridium APM Applic- ation Server -and- Meridium APM Pro- cess Data Integ- ration Server	Required	During the server upgrade process, a backup of your pre- viously used con- figuration file was cre- ated. You can use this pre- upgrade file as a ref- erence to modify the new baseline con- figuration file. You should <i>not</i> overwrite the baseline con- figuration file, You should <i>not</i> overwrite the baseline con- figuration file, as changes may have been made that are required for the service to work cor- rectly. After

Ste- p	Task	Location	Required/Op- tional	Notes
				you modify the baseline con- figuration file, you can delete the pre- upgrade con- figuration file.

Upgrade from any version V3.4.5 through V3.4.5.0.1.4

Ste- p	Task	Location	Required/Op- tional	Notes
1	Specify settings in the file Meridi- um.AHI.Service.exe.config.	Meridium APM Applic- ation Server -and- Meridium APM Pro- cess Data Integ- ration Server	Required	During the server upgrade pro- cess, a backup of your pre- viously used con- figuration file was cre- ated. You can use this pre-upgrade file as a ref- erence to modify the new baseline con- figuration file. You should <i>not</i> overwrite the baseline con- figuration file, as changes may have been made that are required for the service to work cor- rectly. After you modify the baseline

Upgrade or Update Asset Health Manager to V3.6.1.6.0

Ste- p	Task	Location	Required/Op- tional	Notes
				con- figuration file, you can delete the pre-upgrade con- figuration file.

Modifying the File Meridium.AHI.Service.exe.config

When you install the Meridium APM Application Server or the Meridium APM Process Data Integration Service, the Meridium AHM Service and the file *Meridium.AHI.Service.exe.config* are installed automatically. The Meridium AHM Service allows the values in the following Health Indicator record fields to be updated automatically when values change in the primary source record.

- Alert Level
- Last Reading Date
- Last Char Reading Value (for records that accept character values)
- Last Numeric Reading Value (for records that accept numeric values)

Before these values can be updated in this way, you will need to specify settings in the file *Meridium.AHI.Servcice.exe.config* on *both* machines.

The following instructions provide details on modifying the file *Meridi-um.AHI.Servcice.exe.config* manually on the Meridium APM Application Server machine, the Meridium APM Process Data Integration Server, or the Meridium APM Policy Execution Server.

Note: The Application Server and data source that you specify in file *Meridium.AHI.Service.exe.config* must match *exactly* the Application Server and data source in the file *Meridium.PDI.Service.exe.config*.

To modify the file Meridium.AHI.Service.exe.config:

- On the machine on which you are configuring the Meridium AHM Service, navigate to the folder where the Meridium APM Application Server software or the Meridium APM Process Data Integration Service is installed. If you installed the software in the default location, you can locate this file in the following location: C:\Program Files\Meridium\Services.
- 2. Open the file **Meridium.AHI.Service.exe.config** in an application that you can use to modify XML script (e.g., Notepad).
- 3. In the file, within the **<configuration>** tags, locate the following text:

<meridiumconnections>

- 4. Within the **<meridiumconnections>** tags, uncomment the example connection tag by deleting **<!--EXAMPLE:** and the corresponding **-->** from the beginning and end of the string.
- 5. Within **<meridiumconnections>** tags, within the **connection name** attribute, replace **TEST** with a name for the connection to the database. This value is used only by the configuration file.
- 6. If you are modifying the file on the Meridium APM Process Data Integration Server

or the Policy Execution Server.

- a. Within the **<meridiumconnections>** tags, locate the **applicationServer** attribute.
- b. Between the quotations, type the name or IP Address of the Meridium APM Application Server.

-or-

If you are modifying the file on the *Meridium APM Application Server*.

- a. Within the **<meridiumconnections>** tags, locate the **applicationServer** attribute.
- b. If you want the Meridium AHM Service to use a remote connection to the Meridium APM Application Server, between the quotations, type the name or IP Address of the Meridium APM Application Server.

-or-

If you want the AHM Service to use a local connection to the Meridium APM Application Server, accept the default setting (i.e., an empty value).

- Within the <meridiumconnections> tags, within the datasource attribute, replace DVB_ALL_350 with the name of the Meridium APM database that you will use to store your Health Indicator records.
- 8. Within the **<meridiumconnections>** tags, within the **userId** attribute, replace **meridiumUser** with the user name of the user whose credentials should be used to log in to the Meridium APM database specified as the **datasource** value.
- 9. Within the <meridiumConnections> tags, within the password attribute, replace PaSsWoRd with the password that is associated with the user name specified as the userId value. Note that you should not delete the ! in front of the password. This symbol is not part of the password itself. Instead, this symbol will cause the password to be encrypted automatically when the service is restarted.
- 10. Save the file.

Your settings will be applied when you start or restart the Asset Health Indicator Service.

MI AHI Administrator

The following table lists the baseline family-level privileges that exist for the MI AHI Administrator Security Group.

Family	Privileges
Entity Families	
Checkpoint Task	View, Update, Insert
Health Indicator	View, Update, Insert, Delete
Health Indicator Mapping	View, Update, Insert, Delete
Health Indicator Value	View, Update, Insert, Delete
Hierarchy Item Child Definition	View, Update, Insert, Delete
Hierarchy Item Definition	View, Update, Insert, Delete
Measurement Location	View
КРІ	View
KPI Measurement	View
Measurement Location Template	View
Operator Rounds Allowable Values	View
Policy	View
Policy Instance	View
Reading	View
Recommendation	View, Update, Insert, Delete
Timestamped Value	View, Update, Insert, Delete
Xi Reading	View
Xi System	View
Xi Tag	View
Relationship Families	
Has Checkpoint	View
Has Child Hierarchy Item	View, Update, Insert, Delete
Has Health Indicators	View, Update, Insert, Delete

MI AHI Administrator

Family	Privileges
Has Readings	View
Has Recommendations	View, Update, Insert, Delete
Has Timestamped Value	View, Update, Insert, Delete
Has Xi Reading	View
Has Xi Tag	View
Health Indicator Has Mapping	View, Update, Insert, Delete
Health Indicator Has Source	View, Update, Insert, Delete

MI AHI User

The following table lists the baseline family-level privileges that exist for the MI AHI User Security Group.

Family	Privileges
Entity Families	
Checkpoint Task	View, Update, Insert
Health Indicator	View, Update
Health Indicator Mapping	View
Health Indicator Value	View
Hierarchy Item Child Definition	View
Hierarchy Item Definition	View
KPI	View
KPI Measurement	View
Measurement Location	View
Measurement Location Template	View
Operator Rounds Allowable Values	View
Policy	View
Policy Instance	View
Reading	View
Recommendation	View, Update, Insert, Delete
Timestamped Value	View
Xi Reading	View
Xi System	View
Xi Tag	View
Relationship Families	
Has Checkpoint	View
Has Child Hierarchy Item	View
Has Health Indicators	View

Family	Privileges
Has Readings	View
Has Recommendations	View, Update, Insert, Delete
Has Timestamped Value	View
Has Xi Reading	View
Has Xi Tag	View
Health Indicator Has Mapping	View
Health Indicator Has Source	View

AHM User Workflow

The following workflow represents the basic steps that you might use when evaluating a piece of equipment's health using AHM. After you have completed this workflow, you will probably find that you need to repeat certain steps at various times depending on your company's specific needs, changing conditions, and your role within the organization.

These steps assume that Health Indicator records have already been created for the Equipment record identifying the piece of equipment whose health you are evaluating.

- 1. Access the **Asset Health Manager** page for the piece of equipment whose health you want to evaluate. You can do so in either of the following ways:
 - By selecting to view the Equipment record as the root node.
 - By selecting to view the Functional Location record representing the location to which the equipment belongs as the root node.
- 2. Evaluate the piece of equipment's health using the images and data that are displayed on the <u>Asset Health Manager page</u>.
- 3. <u>Acknowledge any warning or alert statuses</u>.
- 4. If needed, <u>create Meridium General Recommendation records to recommend</u> <u>action for the equipment</u>.

About Accessing the Asset Health Manager Page

From the **AHM Start Page**, you can access the **Asset Health Manager** page in the following ways:

- By searching for the specific piece of equipment whose health you want to evaluate.
- By searching for the location containing the equipment whose health you want to evaluate.
- By clicking a link in the **Equipment Technical Number** column in the **Health Indic**ators in Alert section.
- By clicking a link in the **Superior Location** column in the **Health Indicators in Alert** section.

Accessing the Asset Health Manager Page for a Single Piece of Equipment

To access the Asset Health Manager page for a single piece of equipment:

- 1. Access the AHM Start Page.
- 2. In the Links section, click the Search Equipment to View Asset Health link.

The **Find Items** window appears, displaying the **Simple Search** workspace.

🔑 Find Items				×
meridium	Simp	le Search		
Search Type Image: Constraint of the search Image: Constraint of the search Image: Constraint of the search	Search In: Look For:	Equipment Match Case?		Find Now Stop New Search
	🖌 Include Search Field	S		
	Category:	ALL		•
	Class:			-
	Type:	ALL		•
			Open	Cancel

- 3. In the **Search In** list, select the **Equipment** family.
- 4. In the **Look For** text box, type a keyword to limit your results to records containing that word within the Record ID. If you specify a keyword, your results will contain records that match your family criteria and contain the keyword that you specified. A keyword can contain any number of characters, any alphanumeric value, and any special character. A keyword is optional.
- If you want the search to be case-sensitive, select the Match Case check box. Selecting the check box indicates that you want to return only the records that contain the keyword you specified using the exact case that you specified in the Look For text box.

-or-

If you do not want the search to be case-sensitive, do not select the **Match Case** check box.

Note: The Match Case option works only on Oracle schemas. When you perform a search using a SQL Server database, the search will be case- *insensitive* even when the Match Case check box is selected.

- 6. If additional search criteria appear below the **Match Case** check box:
 - If you want to refine the search results further to include only records with specific values in those fields, select the desired values in the available prompts.

-or-

If you do not want to refine the search results further to include only records with specific values in those fields, clear the Include **Search Fields** check box.

Note: If the underlying query prompts have been configured to contain the value *All* by default, if you do not want to refine the search results further, you can accept the default prompt values without clearing the Include Search Fields check box.

7. Click the **Find Now** button.

The search results appear in a grid on the window.

8. Select the Equipment record that represents the piece of equipment whose health you want to evaluate, and click the **Open** button.

The <u>Asset Health Manager<Entity ID> page</u> appears, where **<Entity ID>** is the Record ID of the selected Equipment record. In addition, the Equipment record is represented by the root node in the <u>Health Indicator Explorer pane</u>. The Health Indicator records that are linked to the Equipment record are represented by nodes below the root Equipment node.

🍄 Meridium APM Framework - Asset Health Manager - 🗠 - Water Heater						
Eile Edit Go To Iools Help						
😵 Back 🔹 🗧 Forward 👻 🔄 Refresh 🐐 My Start Page 🔹 🏂 New 🔎 Search 🚞 Catalog 🔞 Query = 🗓 Report = 🕼 Graph = 🥩 Dataset = 💷 Dashboard =						
meridium	Meridium Asset Health Manager - ~ ~ Water Heater					
Asset Health Manager	Health Indicator Explorer	Summary Policies Recommendations				
Common Tasks 🛛 😵	→ ~ Water Heater	All Indicators				
🍓 Print	Condition Check ~ Describe condition	\\OSIPIVM3\Temperature Check 7/17/2012 10:54:49 AM 100 110 120	0 130			
Image: Send To >> Image: Organization of the send to a	Pressure Reading ~ Water Heater, in Time to Hot Water ~ Amount of time i	Condition Check 7/17/2012 3:12:00 PM Good				
Associated Pages 🛛 😵		Duration of Hot Water 7/15/2012 12:00:00 AM				
Create Calibration >> Create Task Create Template >>		Pressure Reading 7/15/2012 12:00:00 AM 40 50 100				
MacroTest		Time to Hot Water 7/15/2012 12:00:00 AM	▼			
	Filters					
	Add Delete	Tir	meZone: Eastern Daylight Time.			

Accessing the Asset Health Manager Page for All Equipment Belonging to a Location

To access the Asset Health Manager page for all equipment belonging to a location:

- 1. Access the AHM Start Page.
- 2. In the Links section, click the Search Functional Locations to View Asset Health link.

The **Find Items** window appears, displaying the **Simple Search** workspace.

差 Find Items		— ×
meridium	Simple Search	
Search Type Simple search	Search In: Functional Location Find Now Look For: Match Case? New Search New Search New Search Stop Stop	
	Open Cancel	

The value in the **Search In** list is set automatically to *Functional Location*. You do not need to modify this value.

- 3. In the **Look For** text box, type a keyword to limit your results to records containing that word within the Record ID. If you specify a keyword, your results will contain records that match your family criteria and contain the keyword that you specified. A keyword can contain any number of characters, any alphanumeric value, and any special character. A keyword is optional.
- 4. If you want the search to be case-sensitive, select the Match Case check box.

Selecting the check box indicates that you want to return only the records that contain the keyword you specified using the exact case that you specified in the **Look For** text box.

-or-

If you do not want the search to be case-sensitive, do not select the **Match Case** check box.

Note: The Match Case option works only on Oracle schemas. When you perform a search using a SQL Server database, the search will be case-*insensitive* even when the Match Case check box is selected.

- 5. If additional search criteria appear below the **Match Case** check box:
 - If you want to refine the search results further to include only records with specific values in those fields, select the desired values in the available prompts.

-or-

If you do not want to refine the search results further to include only records with specific values in those fields, clear the Include **Search Fields** check box

Note: If the underlying query prompts have been configured to contain the value *All* by default, if you do not want to refine the search results further, you can accept the default prompt values without clearing the Include Search Fields check box.

6. Click the **Find Now** button.

The search results appear in a grid on the window.

7. Select the Functional Location record that represents the location containing the equipment whose health you want to evaluate, and click the **Open** button.


The <u>Asset Health Manager<Entity ID> page</u> appears, where **<Entity ID>** is the Record ID of the selected Functional Location record. In addition:

- The selected Functional Location record is represented by the root node in the <u>Health Indicator Explorer pane</u>.
- The successor Functional Location records that are linked to that Functional Location record are represented by nodes below the root node.
- The Equipment records that are linked to the Functional Location records are represented by nodes below those location nodes.

Note: You will need to expand the tree manually to see the Equipment records.

• Health Indicator records that are linked to the Equipment records are represented by nodes below the Equipment nodes.

Note: You will need to expand the tree manually to see the Health Indicator records.



Accessing the Asset Health Manager Page for a Single Piece of Equipment in Alert Condition

The following instructions assume that:

- You have accessed the AHM Start Page.
- The <u>Health Indicators in Alert section</u> on the AHM Start Page displays the Health Indicator records for the piece of equipment whose health you want to evaluate.

To access the Asset Health Manager page for a single piece of equipment that is in alert condition:

• In the **Health Indicators in Alert** section, in the **Equipment Technical Number** column, click the hyperlinked ID of the Equipment record representing the piece of equipment whose health you want to evaluate.

The <u>Asset Health Manager page</u> appears, where the Equipment record is represented by the root node in the <u>Health Indicator Explorer pane</u>. The Health Indicator records that are linked the Equipment record are represented by nodes below the root node in the tree.

Asset Health Manager - WH101 ~ ~ Water Heater							
Health Indicator Explorer △ WH101 ~ ~ Water Heater → \\OSIPIVMS\Temperature Check ~ → Condition Check ~ Describe condition → Duration of Hot Water ~ Measure th	Summary Policies Recommendations All Indicators \\OSIPIVM3\Temperature Check 7/19/2012 1:37:47 PM	100	110	120	110		
Pressure Reading ~ Water Heater, i Time to Hot Water ~ Amount of time	Condition Check 7/17/2012 3:12:00 PM		Good		-		
	Duration of Hot Water 7/15/2012 12:00:00 AM	10	15				
	Pressure Reading 7/15/2012 12:00:00 AM	40	50	100	110		
	Time to Hot Water 7/15/2012 12:00:00 AM			ł	5		

Accessing the Asset Health Manager Page for a Location With at Least One Piece of Equipment in Alert Condition

The following instructions assume that:

- You have accessed the AHM Start Page.
- The <u>Health Indicators in Alert section</u> on the AHM Start Page displays the Health Indicator records for the equipment belonging to the location containing the equipment whose health you want to evaluate.

To access the Asset Health Manager page for a location with at least one piece of equipment in alert condition:

• In the **Health Indicators in Alert** section, in the **Superior Location** column, click the hyperlinked ID of the location containing the equipment whose health you want to evaluate.

The <u>Asset Health Manager page</u> appears, where the Functional Location record is the root node in the <u>Health Indicator Explorer pane</u>. In addition:

- The successor Functional Location records that are linked to that Functional Location record are represented by nodes below the root node.
- The Equipment records that are linked to the lower-level Functional Location records are represented by nodes below those location nodes.

Note: You will need to expand the tree manually to see the Equipment records.

• Health Indicator records that are linked to the Equipment records are represented by nodes below the Equipment nodes.

Note: You will need to expand the tree manually to see the Health Indicator records.

Accessing the Asset Health Manager Page for a Location With at Least One Piece of Equipment in Alert

Meridium APM Framework -	- Asset Health Manager - Plumbing System ~		- • ×
<u>F</u> ile <u>E</u> dit <u>G</u> o To <u>T</u> ools	<u>H</u> elp		
	Refresh 🛭 My Start Page 👻 🎽 New 🔑 Se	arch 🗯 Catalog 🔞 Query + 🛅 Report + 🕼 Graph + 🧐 Dataset + 🛤 Dashboard + 👘	
meridium	Asset Health Manager -	Plumbing System ~	
Asset Health Manager	Health Indicator Explorer	Summary Policies Recommendations	
	Plumbing System ~	All Indicators	
Common Tasks 🛛 😵	HI PL-101 ~		
🎃 Print			
=2 Send To >>			
🕖 Help			
Associated Pages 😵			
	· · ·		
	Filters		
	Add Delete	TimeZone: Ea	astern Daylight Time.

Aspects of the Asset Health Manager Page

The **Asset Health Manager - <Entity ID>** page, where **<Entity ID>** is the field that stores the Record ID of the record represented by the root, contains the following items:

- Task menus: Menus that provide specific functionality. The following task menus are available: <u>Common Tasks</u> and <u>Associated Pages</u>.
- <u>Health Indicator Explorer pane</u>: Displays a tree that contains nodes representing Functional Location records, Equipment records, and the Health Indicator records to which the Equipment records are linked.
- <u>Various tabs</u> that appear or note depending upon the type of node that is selected in the **Health Indicator Explorer** pane.

Throughout the documentation, we refer to the **Asset Health Manager - <Entity ID>** page simply as the **Asset Health Manager** page.

Refreshing the Asset Health Manager Page

You can refresh the **Asset Health Manager** page to ensure that the information displayed on the page for all records reflects up-to-date data from the application server.

To refresh the Asset Health Manager page:

• On the Meridium APM Framework toolbar, click the **Refresh** link.

The **Asset Health Manager** page is refreshed, and the page is displayed according to how it appears when it is first accessed.


For example, the following image shows an example of the **Asset Health Manager** page where the node representing the Health Indicator record *Pressure Reading* is selected in the **Health Indicator Explorer** pane, and the **Stored Data** tab is selected in the workspace.

Asset Health Manager - Plumbing System ~							
Health Indicator Explorer △ Plumbing System ~ PL-101 ~	Current Indicator enters Alert state. Details Trend Stored Data Source		 Image: A state of the state of				
WH101 ~ ~ Water Heater	Reading Date	Reading Value	Status				
\\OSIPIVMS\Temperature Ch	7/15/2012 12:00 AM	115	•				
Condition Check ~ Describe	7/14/2012 12:00 AM	105	•				
Duration of Hot Water ~ Me Pressure Reading ~ Water H Time to Hot Water ~ Amount	7/13/2012 12:00 AM	75					

Continuing with the example, when you click the **Refresh** link, the page is displayed according to how it appears when it is first accessed, as shown in the following image.

Asset Health Manager - Plumbing System ~						
Health Indicator Explorer	Δ	Summary	Policies	s Recommendations		
□ 📥 Plumbing System ~		A	í	Indicators		

Common Tasks Menu



The **Common Tasks** menu on the **Asset Health Manager** page contains the following links:

- **Print:** Displays the **Print** dialog box, where you can select the desired printer and settings.
- **Send To:** Displays a submenu with options that let you send a link to the current page to your desktop (create shortcut), in an email message, or a Home Page.
- Help: Displays the context-sensitive Help topic for the Asset Health Manager page.

Associated Pages Menu

The **Associated Pages** menu on the **Asset Health Manager** page displays Associated Pages that are configured for the family of the currently selected node. For example, if you select the root node that represents an Equipment record, the **Associated Pages** menu will display Associated Pages that are configured for the Equipment family.


About the Health Indicator Explorer Pane

The **Health Indicator Explorer** pane on the **Asset Health Manager** page displays a tree that contains nodes representing an Equipment or Functional Location record and the Health Indicator records to which the Equipment record is linked. By default, the Health Indicator nodes are listed in alphabetical order. If desired, you can also <u>sort the Health Indicator nodes in descending order</u>.

In the tree, the root node either represents a Functional Location record or an Equipment record, depending upon the way in which you <u>accessed the page</u>. Below the Equipment node are nodes representing the Health Indicator records to which that Equipment record is linked.

For example, in the following image:

- The root node *Plumbing System* ~ represents a Functional Location record.
- Its subnode *PL-101* ~ represents a Functional Location record that is linked as a successor to the *Plumbing System* ~ Functional Location record.
- Its subnode *WH101 ~ ~ Water Heater* represents an Equipment record.
- Its subnodes represent Health Indicator records that are linked to the Equipment record.



All Functional Location and Equipment nodes are represented by a colored triangle, and the Health Indicator nodes are represented by colored circles.

A circle can be any of the following colors:

• **Red:** Indicates that the corresponding Health Indicator record meets Alert <u>status</u> criteria.

Note: A red circle that contains a green check mark represents a Health Indicator record that has been <u>acknowledged</u>.


• Yellow: Indicates that the corresponding Health Indicator record meets Warning <u>status</u> criteria.

Note: A yellow circle that contains a green check mark represents a Health Indicator record that has been <u>acknowledged</u>.

- **Green:** Indicates that the corresponding Health Indicator record meets Normal <u>status</u> criteria.
- White: Indicates that the corresponding Health Indicator record is not linked to a primary source record.
- **Gray:** Indicates that the primary source record of the corresponding Health Indicator record is not associated with any secondary source records. For example, if the primary source record is a Measurement Location record, the circle will be gray if the Measurement Location record is not linked to any Reading records.

The triangles for the nodes representing the Equipment and Functional Location records can be any of the following colors:

- **Gray:** Indicates that the Equipment record is not linked to any Health Indicator records.
- **Green:** Indicates that the Equipment record is linked only to Health Indicator records that meet Normal status criteria.
- Yellow or Red: Indicates the *worst* status among all of the Health Indicator records that are linked to the Equipment record. If the Equipment record is linked to one or more Health Indicator records that meet Warning or Alert status criteria, the triangle for the associated Functional Location and Equipment nodes will be colored according to the worst status of those Health Indicator records. Consider the following image.



In this image, the triangles are red because at least one of the Health Indicator nodes has a red circle, indicating that the Health Indicator record meets Alert status criteria.

The following options appear below the tree in the **Health Indicator Explorer** pane:

• Filter link: Displays the <u>Manage Filters window</u>, which provides options you can use to <u>limit the nodes that appear in the Health Indicator Explorer pane</u>.

Note: After you apply a filter, text identifying the filter will appear below the tree. In addition, a **Clear All** link will also appear, which you can use to remove all the filters that you have applied.

• Add button: Displays the Health Indicator Builder, where you can create new Health Indicator records that are linked to the Equipment record represented by the selected Equipment node.

Note: The **Add** button is enabled only if you are a member of the MI AHI Administrator Security Group.

• **Delete button:** After asking for confirmation, <u>deletes the selected Health Indicator</u> <u>record</u>.


Note: The **Delete** button is enabled only if you are a member of the MI AHI Administrator Security Group.

Sorting Nodes in the Health Indicator Explorer Pane

By default, the Health Indicator nodes that are displayed in the tree in the **Health Indicator Explorer** pane are sorted alphabetically. In addition, on the **Summary** tab, the gauges that are associated with the nodes are sorted alphabetically.

To sort the nodes and their associated gauges in descending order:

• Click the bar that displays the title of the Health Indicator Explorer pane.



The Health Indicator nodes and the gauges are sorted in descending order.

Accessing the Manage Filters Window

You can use the **Manage Filters** window to select the filters that you want to use to limit the Health Indicator nodes that are displayed in the **Health Indicator Explorer** pane.

To access the Manage Filters window:

• In the Health Indicator Explorer pane, below the tree, click the Filters link.

The Manage Filters window appears.

🛞 Ma	anage Filters				×
Stand	ard Filters				
	Apply?	Filter			
		Hide assets with Health Indicator	S		
		Hide assets without Health Indica	itors		
		Hide Normal Health Indicators			
		Hide Warning Health Indicators			
		Hide Alert Health Indicators			
		Hide Health Indicators with Source			
		Hide Health Indicators without So	ource		
Custo	m Filters				
	Apply?	Field	Operator	Value	
*					
			ОК	Cancel Help	
			UK	Cancer Help	

Aspects of the Manage Filters Window

The Manage Filters window contains the following sections:

- Standard Filters: Displays a list of <u>baseline filters that you can apply to the nodes</u> in the Health Indicator Explorer pane.
- **Custom Filters:** Displays a grid where you can <u>create custom filters that you can</u> apply to the nodes in the **Health Indicator Explorer** pane.

Applying Filters

To apply one or more filters to the Health Indicator nodes in the tree:

- 1. Access the Manage Filters window.
- 2. In either section, in the row containing the filter that you want to apply to the Health Indicator nodes, select the **Apply** check box.
- 3. Click OK.

The tree in the **Health Indicator Explorer** pane is refreshed and displays only the Health Indicator nodes whose Health Indicator records meet the filtering criteria. In addition, the **Summary** tab is updated to show information only for nodes that are displayed in the tree.

In addition, at the bottom of the tree, you will see text describing the selected filters and an option to <u>clear the filters</u>.

Note: If you selected the Hide assets with Health Indicators or Hide assets without Health Indicators filter and the filter should hide a parent node but not its child node, the parent node will still appear in the tree.

Clearing Filters

Filters that have been applied to the tree in the **Health Indicator Explorer** pane can be cleared one at a time or all at once using the following methods:

To clear a single filter:

• Below the tree in the **Health Indicator Explorer** pane, beside the filter that you want to remove, click the **x** button.

The **Health Indicator Explorer** pane is refreshed to show the nodes that were previously filtered.

To clear all filters:

• Below the tree in the Health Indicator Explorer pane, click the Clear All link.

The **Health Indicator Explorer** pane is refreshed to show the nodes that were previously filtered.

Creating Custom Filters

When you create and apply custom filters, rather than *excluding* the Health Indicator nodes that you do not want to see in the tree, the filter criteria that you choose will determine which Health Indicator nodes you want to *include* in the tree.

For example, when you apply the standard filter *Hide Normal Health Indicators*, any Health Indicator node whose Health Indicator record meets the *Normal* status will be hidden, and only Health Indicator nodes whose Health Indicator records meet either the *Warning* or *Alert* status will appear in the tree.

By contrast, if you create and apply the custom filter*Acknowledged = True*, the only Health Indicator nodes that will be represented in the tree are those that have been acknowledged.

Note: If you create a custom filter from scratch, it will be applied automatically to the tree in the **Health Indicator Explorer** pane. If you <u>clear the filter</u>, you can still select it on the **Manage Filters** window to <u>apply it to the tree</u>. In addition, you can modify or <u>delete the custom filter</u> via this window.

To create a custom filter:

- 1. Access the Manage Filters window.
- 2. In the **Custom Filters** section, in the first empty row, define the desired filter. To do so:
 - a. In the **Field** cell, click the **v** button, and select the field that applies to the filter you want to create. The list displays all fields in the Health Indicator family.
 - b. In the **Operator** cell, click the **v** button, and select the operator that you want to apply to the selected field.
 - c. In the **Value** cell, type or select the value to which the selected operator should be applied.

For example, to display only Health Indicator nodes that have not been acknowledged, the filter would look like this:

	Apply?	Field	Operator	Value
►		Acknowledged	=	False

3. Click OK.

The **Health Indicator Explorer** pane is refreshed, and the tree displays the nodes that meet the filtering criteria.

Deleting Custom Filters

To delete a custom filter:

- 1. Access the Manage Filters window.
- In the row containing the filter that you want to remove, in the Field cell, click thebutton, and select the empty value at the top of the list.
- 3. Click OK.

The filter is removed from the Manage Filters window.

About the Tabs

The tabs that appear on the **Asset Health Manager** page change depending upon the node that is selected in the <u>Health Indicator Explorer pane</u>.

- When an Equipment node is selected in the **Health Indicator Explorer** pane, the following tabs are displayed:
 - <u>Summary</u>: Displays a graphical representation of the overall health of the piece of equipment.
 - **Policies:** Displays the policy instances that include that Equipment record.
 - <u>Recommendations</u>: Displays the Recommendation records that are linked to the Equipment record.
 - <u>Events</u>: Displays event data in source event records that are linked to the Equipment record.

In the following image, you can see that the Equipment node is selected in the **Health Indicator Explorer** pane, and the tabs described above are displayed to the right of the tree.


Health Indicator Explorer	Summary	Policies Recommendations Events				
Plumbing System ~	A	I Indicators				
PL-101 ~ WH101 ~ ~ Water Heater		\\OSIPIVM3\Temperature Check 7/19/2012 1:37:47 PM	100	110	120	130
		Condition Check 7/17/2012 3:12:00 PM	_	Good	1	
		Duration of Hot Water 7/15/2012 12:00:00 AM	10	15		
		Pressure Reading 7/15/2012 12:00:00 AM	40	50	100	110
		Time to Hot Water 7/15/2012 12:00:00 AM			i	5

- When a Health Indicator node is select in the **Health Indicator Explorer** pane, the following tabs are displayed:
 - <u>Details</u>: Displays the values in the Name and Description fields in the Health Indicator record represented by the selected node. If the Health Indicator record was created via Policy Manager, additional information is also displayed on this tab.
 - Trend: Displays a graph that provides a historical view of the data that is stored in the associated reading records or process historians.
 - <u>Stored Data</u>: Displays reading values that are stored in the associated reading records.
 - **Snapshot:** Displays reading values that are stored in a process historian.

Note: This tab appears only when the primary source record is an Xi Tag record.

 <u>Source</u>: Displays the datasheet of the primary source record that is linked to the Health Indicator record represented by the selected node.

In the following image, you can see that a Health Indicator node is selected in the **Health Indicator Explorer** pane, and the tabs described above are displayed to the right of the tree. Note that the **Snapshot** tab is not available because the primary source record that is represented by the selected node is a Measurement Location record.



Several buttons appear above the tabs, depending upon the status of the Health Indicator record that is represented by the selected node. The following table describes the buttons that are available and information about when those buttons appear.

Button	Description	Notes	
	Displays the Acknowledgement Note dialog box, where you can <u>acknow</u> - <u>ledge</u> the condition.	This button appears only if the selec- ted Health Indicator node represents a Health Indicator record with a status other than Normal (e.g., Alert) that has not been acknowledged.	

Button	Description	Notes
40	After displaying a confirmation mes- sage, revokes the acknowledgement.	This button appears only if the selec- ted node represents a Health Indic- ator record whose status is currently acknowledged.
	Displays the Acknowledgement Note dialog box, where you can modify the note that is currently associated with a Health Indicator record.	This button appears and is enabled only if the selected node represents a Health Indicator record whose status is currently acknowledged. If the selected node represents a Health Indicator record whose status is Alert or Warning but has not been acknowledged, this button appears but is disabled.
*	Displays a new Meridium General Recommendation record that you can use to <u>recommend action for the</u> <u>piece of equipment whose health</u> <u>you are evaluating</u> .	This button always appears.

About the Summary Tab

The **Summary** tab is displayed when an Equipment node is selected in the **Health Indic**ator Explorer pane. The **Summary** tab is displayed by default when you <u>access the Asset</u> <u>Health Manager page</u>.

The following image shows an example of the **Summary** tab.

Asset Health Manager -	Plumbing System ~				
Health Indicator Explorer	Summary Policies Recommendations				
□·▲ Plumbing System ~	All Indicators				
PL-101 ~	Voctory (N2) Terresenture Charle	▼			
WH101 ~ ~ Water Heater	<u>\\OSIPIVM3\Temperature Check</u> 7/19/2012 1:37:47 PM	100	110	120	130
Condition Check ~ Describe	Condition Check				
Duration of Hot Water ~ Me Pressure Reading ~ Water H	7/17/2012 3:12:00 PM		Go	od	
Time to Hot Water ~ Amount	Duration of Hot Water 7/15/2012 12:00:00 AM	10	15	_	
	Pressure Reading 7/15/2012 12:00:00 AM	40	50	100	110
	Time to Hot Water 7/15/2012 12:00:00 AM			i	5

The **Summary** tab displays various rows, where each row represents a Health Indicator record that is linked to the Equipment record represented by the selected node.

Each row contains the following items:

- A check box that appears if the Health Indicator record's status:
 - Is either Warning or Alert.
 - and -
 - Has not been acknowledged.

When you select the check box, the following additional buttons appear above the top row (on the far right):

- Displays the Acknowledgement Note dialog box where you can acknowledge the condition.
- Displays a new Meridium General Recommendation record.

Note: You can select the Health Indicators individually or all at once by selecting the All check box above the grid.

• The Health Indicator Record ID as it appears in the **Health Indicator Explorer** pane. The Health Indicator Record IDs are hyperlinks that you can click to access the <u>Trend tab</u> for that Health Indicator record. • A <u>gauge</u> that represents the current health of the equipment with respect to that indicator.

About the Gauges

Gauges appear on the <u>Summary tab</u> when an Equipment node is selected in the <u>Health</u> <u>Indicator Explorer pane</u>. Each gauge contains:

- Various colored sections that represent the status criteria that the Health Indicator record could meet.
- Specific values depending upon the type of primary source record that is linked to the Health Indicator record. These values indicate one of the following items:
 - Target and critical reading values (i.e., in KPI records).
 - The current reading value (i.e., in Measurement Location and Xi Tag records that accept character values).
 - Upper and lower level limits (i.e., in Measurement Location and Xi Tag records that accept numeric values).
- A black triangle that identifies the most recent reading value for the Health Indicator.


Note: If there is not a reading value stored in the Health Indicator record, the black triangle will not appear above the gauge.

The following types of gauges will appear on the **Summary** tab:

- <u>Gauges representing data in Measurement Location records that accept numeric</u> <u>readings</u>.
- <u>Gauges representing data in Measurement Location records that accept character</u><u>readings.</u>
- Gauges representing data in KPI records where low values are good.
- Gauges representing data in KPI records where high values are good.
- Gauges representing data in Xi Tag records that accept numeric readings.
- Gauges representing data in Xi Tag records that accept character readings.

Interpreting Gauges Representing Numeric Measurement Locations

The following image shows an example of a gauge that represents a Measurement Location record that accepts numeric reading values.



In this image, you can see that the gauge contains various colored sections that correspond to <u>status criteria</u> that the Health Indicator record could meet. Note that the status of a Health Indicator record that is linked to a Measurement Location record that accepts numeric values is determined based upon:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The limit values in the Measurement Location record (which are displayed on the Limit Values tab on the Measurement Location datasheet).

The black triangle on the gauge represents the value stored in the Last Numeric Reading Value field in the Health Indicator record. If the *Meridium.AHI.Service.exe.config* file has been <u>configured</u> properly, this value is updated automatically by the AHM Service.

On gauges that represent Measurement Location records that accept numeric readings, the values that appear below the gauge represent limit values, which are displayed on the **Limit Values** tab of the Measurement Location datasheet. Note, however, that the *Numeric Upper Level 3* and *Numeric Lower Level 3* values are not shown below the gauge. These values represent the highest and lowest reading values that can be recorded.

- Numeric Upper Level 3 = 120
- Numeric Upper Level 2 = 110
- Numeric Upper Level 1 = 100
- Numeric Lower Level 1 = 50
- Numeric Lower Level 2 = 40
- Numeric Lower Level 3 = 30

The following table describes the classifications of reading values that appear on gauges that represent this type of record and their associated color on the gauge.

Range	Description	Section color on gauge
Normal	The reading value falls between the values in the Lower Level 1 field and the Upper Level 1 field in the Measurement Location record.	Green
Warning	 The reading values meets either of the following conditions: The reading value is greater than or equal to the value in the Lower Level 1 field and less than the value in the Lower Level 2 field in the Measurement Location record. -Or- The reading value is greater than or equal to the value in the Upper Level 1 field and less than the value in the Upper Level 1 field and less than the value in the Upper Level 2 field in the Measurement Location record. 	Yellow
Alert	 The reading value meets either of the following conditions: The reading value is greater than or equal to the value in the Lower Level 2 field in the Measurement Location record. The reading value is greater than or equal to the value in the Upper Level 2 field in the Measurement Location record. 	Red


Note that the gauge does not display the actual reading value. Instead, its purpose is to indicate where the current reading value falls within a range of acceptable and unacceptable values. In the example image, you can see that the black triangle falls within a red section, meaning that the Health Indicator record meets the Alert status criteria.

To the left of the gauge, you can see:

- The hyperlinked name of the Health Indicator record that is linked to the Measurement Location record. You can click the hyperlink to access the <u>Trend tab</u>, where you can view a graph that shows historical data for the health indicator.
- The date and time on which the reading value represented on the gauge was recorded, as stored in the Last Reading Date field in the Health Indicator record.

Interpreting Gauges Representing Character Measurement Locations

The following image shows an example of a gauge that represents a Measurement Location record that accepts character reading values.



In this image, you can see that the gauge contains various colored sections that correspond to <u>status criteria</u> that the Health Indicator record could meet. Note that the status of a Health Indicator record that is linked to a Measurement Location record that accepts character values is determined based upon:

- The value stored in the Last Char Reading Value field in the Health Indicator record.
- The limit values in the Measurement Location record (which are displayed on the Limit Values tab on the Measurement Location datasheet).

The black triangle on the gauge represents the value stored in the Last Char Reading Value field in the Health Indicator record. If the *Meridium.AHI.Service.exe.config* file has been <u>configured</u> properly, this value is updated automatically by the AHM Service.

In this example, the Measurement Location record measures the condition of a water heater via a visual check by an operator. In this case, the allowable values are *Good*, *Poor*, and *Critical*. Note that for Measurement Location records that accept character values, the gauge displays the latest reading value. In the example shown above, the most recent reading value is *Good*.

The following table describes the classifications of reading values that appear on gauges that represent this type of record and their associated color on the gauge.

Range	Description	Section color on gauge
Normal	The reading value does not appear on the Limit Values tab in the Measurement Loca- tion record. In the example, the value <i>Good</i> is consistent with the status <i>Normal</i> .	Green
Warning	The reading value appears on the Limit Val- ues tab in either the Lower Level 1 or Upper Level 1 cells in the Measurement Location record. In the example, the value <i>Poor</i> is consistent with the status <i>Warning</i> .	Yellow

Range	Description	Section color on gauge
Alert	The reading value appears on the Limit Values tab in the Lower Level 2, Upper Level 2, Lower Level 3, or Upper Level 3 cells in the Measurement Location record. In the example, the value <i>Critical</i> is consistent with the status <i>Alert</i> .	Red

Notice that the gauge also displays a gray section to the left of the green section. This section is shaded gray because a value cannot be better than normal.

To the left of the gauge, you can see:

- The hyperlinked name of the Health Indicator record that is linked to the Measurement Location record. You can click the hyperlink to access the <u>Trend tab</u>, where you can view a graph that shows historical data for the health indicator.
- The date and time on which the reading value represented on the gauge was recorded, as stored in the Last Reading Date field in the Health Indicator record.

Interpreting Gauges Representing KPIs Where Low Values are Good

The following image shows an example of a gauge that represents a KPI record where low values are good.



In this image, you can see that the gauge displays various colored sections that correspond to <u>status criteria</u> that the Health Indicator record could meet. For KPI data where low values are good, the status colors are organized left to right, from best status to worst status. Note that the status of Health Indicator record that is linked to a KPI record is determined based upon:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The Target and Critical values that are stored in the most recent KPI Measurement record that is linked to the KPI record.

Note: Because these limit values are stored in secondary source records (i.e., KPI Measurement records), they are not displayed on the KPI datasheet. Instead, you can view these values by opening the most recent KPI Measurement record in Record Manager.

The black triangle on the gauge represents the value stored in the Last Numeric Reading Value filed in the Health Indicator record. If the *Meridium.AHI.Service.exe.config* file has been <u>configured</u> properly, this value is updated automatically by the AHM Service.

The values displayed on the gauge represent limit values that are stored in the linked KPI Measurement record. In the preceding image, the value *1* represents the Target value, and the value *5* represents the Critical value. In this example, the KPI measures the time it takes for the faucet to yield hot water, where a low number is preferred.

The following table describes the classifications of reading values that appear on gauges that represent this type of record and their associated color on the gauge.

Range	Description	Section color on gauge
Normal	The value stored in the Last Numeric Reading Value field is less than the Target value.	Green

Range	Description	Section color on gauge
Warning	The value stored in the Last Numeric Reading Value field is greater than or equal to the Target value and less than the Critical value.	Yellow
Alert	The value stored in the Last Numeric Reading Value field is greater than or equal to the Critical value.	Red

Notice that the gauge also displays a gray section to the left of the green section. This section is shaded gray because a value cannot be better than normal. When a low number is preferred for a KPI, *any* number below the Target value is considered *Normal*.


Note that the gauge does not display the actual measurement value. Instead, its purpose is to indicate where the value falls within a range of acceptable and unacceptable values. In the image, you can see that the black triangle falls within a yellow section, meaning that the Health Indicator record meets the Warning status criteria.

To the left of the gauge, you can see:

- The hyperlinked name of the Health Indicator record that is linked to the KPI record. You can click the hyperlink to access the <u>Trend tab</u>, where you can view a graph that shows historical data for the health indicator.
- The date and time on which the reading value represented on the gauge was recorded, as stored in the Last Reading Date field in the Health Indicator record.

Interpreting Gauges Representing KPIs Where High Values are Good

The following image shows an example of a gauge that represents a KPI record where high values are good.



In this image, you can see that the gauge displays various colored sections that correspond to <u>status criteria</u> that the Health Indicator record could meet. For KPI data where high values are good, the status colors are organized left to right, from worst status to best status. Note that the status of Health Indicator record that is linked to a KPI record is determined based upon:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The Target and Critical values that are stored in the most recent KPI Measurement record that is linked to the KPI record.

Note: Because these limit values are stored in secondary source records (i.e., KPI Measurement records), they are not displayed on the KPI datasheet. Instead, you can view these values by opening the most recent KPI Measurement record in Record Manager.

The black triangle on the gauge represents the value stored in the Last Numeric Reading Value filed in the Health Indicator record. If the *Meridium.AHI.Service.exe.config* file has been <u>configured</u> properly, this value is updated automatically by the AHM Service.

The values displayed on the gauge represent limit values that are stored in the linked KPI Measurement record. In the preceding image, the value *15* represents the Target value, and the value *10* represents the Critical value. In this example, the KPI measures the number of minutes that the faucet yields hot water, where a high number is preferred.

The following table describes the classifications of reading values that appear on gauges that represent this type of record and their associated color on the gauge.

Range	Description	Section color on gauge
Normal	The value stored in the Last Numeric Reading Value field is greater than the Target value.	Green

Range	Description	Section color on gauge
Warning	The value stored in the Last Numeric Reading Value field is less than or equal to the Target value and greater than the Critical value.	Yellow
Alert	The value stored in the Last Numeric Reading Value field is less than or equal to the Critical value.	Red

Notice that the gauge also displays a gray section the right of the green section. This section is shaded gray because a value cannot be better than normal. When a high number is preferred for a KPI, *any* number above the Target value is considered *Normal*.


Note that the gauge does not display the actual measurement value. Instead, its purpose is to indicate where the value falls within a range of acceptable and unacceptable values. In the image, you can see that the black triangle falls within a green section, meaning that the Health Indicator record meets the Normal status criteria.

To the left of the gauge, you can see:

- The hyperlinked name of the Health Indicator record that is linked to the KPI record. You can click the hyperlink to access the <u>Trend tab</u>, where you can view a graph that shows historical data for the health indicator.
- The date and time on which the reading value represented on the gauge was recorded, as stored in the Last Reading Date field in the Health Indicator record.

Interpreting Gauges Representing Numeric Xi Tags

The following image shows an example of a gauge that represents an XI Tag record that accepts numeric reading values.



In this image, you can see that the gauge displays various colored sections that correspond to <u>status criteria</u> that the Health Indicator record could meet. Note that the status of a Health Indicator record that is linked to an Xi Tag record that accepts numeric values is determined based upon:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The limit values in the Xi Tag record (which are displayed on the Limit Values tab on the Xi Tag datasheet).

The black triangle on the gauge represents the value stored in the Last Numeric Reading Value field in the Health Indicator record. If the *Meridium.AHI.Service.exe.config* file has been <u>configured</u> properly, this value is updated automatically by the AHM Service.

On gauges that represent Xi Tag records that accept numeric readings, the values that appear below the gauge represent readings that are displayed on the **Limit Values** tab on the Xi Tag datasheet. In this example, the values that are shown on the image are stored in the Xi Tag record as described in the following list. Note that the *Numeric Upper Level 3* and *Numeric Lower Level 3* values are not shown below the gauge. These values represent the highest and lowest reading values that can be recorded.

- Numeric Upper Level 3 = 140
- Numeric Upper Level 2 = 130
- Numeric Upper Level 1 = 120
- Numeric Lower Level 1 = 110
- Numeric Lower Level 2 = 100
- Numeric Lower Level 3 = 90

The following table describes the classifications of reading values that appear on gauges that represent this type of record and their associated color on the gauge.

Range	Description	Section color on gauge
Normal	The reading value falls between the values in the Numeric Lower Level 1 field and the Numeric Upper Level 1 field in the Xi Tag record.	Green
Warning	The reading value meets either of the following conditions:The reading value is greater than or	Yellow
	equal to the value in the Numeric Lower Level 1 field and less than the value in the Numeric Lower Level 2 field in the Xi Tag record.	
	-or-	
	• The reading value is greater than or equal to the value in the Numeric Upper Level 1 field and less than the value in the Numeric Upper Level 2 field in the Xi Tag record.	
Alert	The reading value meets either of the fol- lowing conditions:	Red
	 The reading value is greater than or equal to the value in the Numeric Lower Level 2 field in the Xi Tag record. 	
	• The reading value is greater than or equal to the value in the Numeric Upper Level 2 field in the Xi Tag record.	

Note that the gauge does not display the actual reading value. Instead, its purpose is to indicate where the reading value falls within a range of acceptable and unacceptable values. In the image, you can see that the black triangle falls within a yellow section, meaning that the Health Indicator record meets the Warning status criteria.


To the left of the gauge, you can see:

• The hyperlinked name of the Health Indicator record that is linked to the Xi Tag record. You can click the hyperlink to access the <u>Trend tab</u>, where you can view a graph that shows historical data for the health indicator.

• The date and time on which the reading value represented on the gauge was recorded, as stored in the Last Reading Date field in the Health Indicator record.

Interpreting Gauges Representing Character Xi Tags

The following image shows an example of a gauge that represents an Xi Tag record that accepts character reading values.



In this image, you can see that the gauge contains various colored sections that correspond to the <u>status criteria</u> that the Health Indicator record could meet. Note that the status of the Health Indicator record is linked to an Xi Tag record that accepts character values is determined based upon:

- The value stored in the Last Char Reading Value field in the Health Indicator record.
- The limit values in the Xi Tag record (which are displayed on the Limit Values tab on the Xi Tag datasheet.

The black triangle on the gauge represents the value that is stored in the Last Char Reading Value field in the Health Indicator record. If the *Meridium.AHI.Service.exe.config* file has been configured properly, this value is updated automatically by the AHM Service.

In this example, the Xi Tag record measure the condition of the pressure valve on a water heater. In this case, the allowable values for the visual check are *Good*, *Poor*, and *Critical*. Note that for Xi Tag records that accept character values, the gauge displays the most recent reading value. In the image displayed in this topic, the most recent reading value is *Good*.

The following table describes the classifications of reading value ranges that appear on gauges that represent this type of record and their associated color on the gauge.

Range	Description	Section color on gauge
Normal	The reading value does not appear on the Limit Values tab in the Xi Tag record. In the example, the value <i>Good</i> is consistent with the status <i>Normal</i> .	Green
Warning	The reading value appears on the Limit Values tab in either the Lower Level 1 or Upper Level 1 cells in the Xi Tag record. In the example, the value <i>Poor</i> is consistent with the status <i>Warning</i> .	Yellow
Alert	The reading value appears on the Limit Values tab in the Lower Level 2 , Upper Level 2 , Lower Level 3 , or Upper Level 3 cells in the Xi Tag record. In the example, the value <i>Critical</i> is consistent with the status <i>Alert</i> .	Red

Notice that the gauge also displays a gray section to the left of the green section. This section is shaded gray because a value cannot be better than normal.

To the left of the gauge, you can see:

- The hyperlinked name of the Health Indicator record that is linked to the Xi Tag record. You can click the hyperlink to access the <u>Trend tab</u>, where you can view a graph that shows historical data for the health indicator.
- The date and time on which the reading value represented on the gauge was recorded, as stored in the Last Reading Date field in the Health Indicator record.

Policies Tab

The **Policies** tab appears when an Equipment node is selected in the **Health Indicator Explorer** pane. The **Policies** tab contains a grid that displays the results of the Policy query, which is stored in the Catalog folder \\Public\Meridium\Modules\AHI\Queries.

The following image shows an example of the **Policies** tab as it appears on the **Asset Health Manager** page.

Asset Health Manager - Plumbing System ~						
Health Indicator Explorer	S	ummary Policies Recor	nmendations			
□ ▲ Plumbing System ~	Г	Instance ID	Policy	Active	Last Executed	Message
PL-101 ~	IL,	Instance 1	UC1 Vision FXD	True		
─▲ WH101 ~ ~ Water Heater	ľĽ	Instance I		nue		
Condition Check ~ Describe						
···· — Duration of Hot Water ~ Me						
Pressure Reading ~ Water H						
Time to Hot Water ~ Amount						

The grid that appears on the **Policies** tab contains a separate row for each policy instance that includes the Equipment record. The grid contains the following columns:

- **Instance ID:** The ID of the policy instance (as it is stored in the ID field in the Policy Instance record).
- **Policy:** The name of the policy (as it is stored in the Name field in the Policy record) that is associated with the policy instance.

Note: The values in the Policy column appear as hyperlinks, which you can click to access the **Policy** page for that policy.

- Active: A value that indicates whether the policy instance is *active*(*Yes*) or *inactive* (*No*). This value is stored in the Active field in the associated Policy Instance record. You can <u>activate an inactive policy</u> instance by clicking the **Activate** button, which appears when you click inside the **Active** cell.
- Last Executed: The date and time that the policy instance was last executed.
- Message: Details about the last execution of the policy instance.

Recommendations Tab

The **Recommendations** tab is displayed when an Equipment record is selected in the **Health Indicator Explorer** pane. The following image shows an example of the **Recommendations** tab as it appears on the **Asset Health Manager** page.

Asset Health Manager - Plumbing System ~					
Health Indicator Explorer △	Su	ummary Policies R	Recommendations		Manage Recommendations
PL-101 ~ WH101 ~ ~ Water Heater	Ę	Current State	Recommendation ID	Recommendation Type	Recommendation Headline
OSIPIVMS\Temperature Ch Condition Check ~ Describe	Ľ	Open	REC-1348	PCY	Policy Recommendation for water heater
Duration of Hot Water ~ Me Pressure Reading ~ Water H Time to Hot Water ~ Amount					

The **Recommendations** tab contains a grid that displays the results of the <u>Recommendations query</u> that is stored in the Catalog location \\Public\Meridium\Modules\AHI. One row is displayed in the grid for each Recommendation record that is linked to the selected Equipment record. The grid contains the following columns that correspond with values in the Recommendation record:

- Recommendation ID
- Recommendation Type
- Recommendation Headline
- Recommendation Description

One additional column, **Current State**, is displayed, which corresponds with the state of the Recommendation record.

Above the grid, the **Manage Recommendations** link appears, which provides access the **Recommendation Management** page where you can view and manage the Recommendation records that are linked to the selected Equipment record.

Details Tab

The **Details** tab appears when a Health Indicator node is selected in the **Health Indicator Explorer** pane. The following image shows an example of the **Details** tab as it appears on the **Asset Health Manager** page.

Asset Health Manager - Plumbing System ~						
Health Indicator Explorer	Current Indicator enters Alert state.					
□·▲ Plumbing System ~	Details Trend Stored Data Source					
📃 📥 WH101 ~ 🛛 Water Heater	Name Pressure Reading					
\\OSIPIVMS\Temperature Ch						
Condition Check ~ Describe	Description Water Heater, internal PSI					
Duration of Hot Water ~ Me						
Pressure Reading ~ Water H						
Time to Hot Water ~ Amount						

The **Details** tab contains the following text boxes:

- Name: Displays the name of the Health Indicator record that is represented by the selected node. The Name text box is populated automatically with the value stored in the Source Name Field field in the Health Indicator Mapping record.
- **Description:** Displays a description of the Health Indicator record that is represented by the selected node. The value in this text box is stored in the Description field in the Health Indicator record.

Note: The **Description** text box is empty when the Health Indicator record is created in AHM (as opposed to Policy Manager).

If you want to <u>change the name or description of a Health Indicator record</u>, you can modify the values that appear in the **Name** and **Description** text boxes.

When a Health Indicator record that was created via Policy Manager is selected in the **Health Indicator Explorer** pane, the **Limit Values** workspace is displayed below the text boxes on the **Details** tab. The following image shows an example of the **Limit Values** workspace.

Asset Health Manager - ~	PUMP 1~ HXST 152
Health Indicator Explorer \rightarrow Image: Constraint of the state	Current Health Indicator is out of sync with latest data. Details Trend Stored Data Source Name Pump Health Index Description Composite of Flow Rate, Pressure, Lubrication, General Operation, and Vibration for Pump 1 Umit Values Upper Level 3 140 Upper Level 2 125 Upper Level 1 115 Lower Level 1 90 Lower Level 3 70
Add Delete	

The **Limit Values** workspace contains the text boxes that correspond with fields in the Health Indicator record, which are outlined in the following table.

Text box	Health Indicator field
Upper Level 3	Upper Level 3 Alert
Upper Level 2	Upper Level 2 Alert
Upper Level 1	Upper Level 1 Alert
Lower Level 1	Lower Level 1 Alert
Lower Level 2	Lower Level 2 Alert
Lower Level 3	Lower Level 3 Alert


You can use these text boxes to modify the limit values in the Health Indicator record.

About the Trend Tab

The **Trend** tab appears when the following criteria are satisfied:

- A Health Indicator node is selected in the Health Indicator Explorer pane.
 - and -
- The primary source record of the corresponding Health Indicator record is linked to at least one secondary source record or process historian that contains reading values.

If these conditions are met, the **Trend** tab will appear by default when you select a Health Indicator node in the tree. The following image shows an example of the **Trend** tab.



The **Trend** tab contains the following items:

• <u>Graph</u>: A line graph that illustrates how readings have fluctuated over time for a particular health indicator. The graph that is displayed on the **Trend** tab is built using the same graphing tool that is used to display data on the **Process Data Viewer** window, which is used to display reading values for tags represented by Xi Tag records.

Note: The graph on the **Trend** tab does not offer the same options that are available for standard graphs throughout the rest of the Meridium APM Framework application.


- <u>Data Range criteria</u>: Defines the specific date range for which data will be displayed on the graph.
- <u>Zoom buttons</u>: Allow you to select a predetermined amount of data that will be displayed on the graph.

The graph plots the readings values that exist for the health indicator. Specifically:


- If the primary source record is a Measurement Location record, the graph displays a history of reading values that are stored in secondary source records, (i.e., Reading records that are linked to the Measurement Location record).
- If the primary source record is a KPI record, the graph displays a history of measurement values that are stored in secondary source records, (i.e., KPI Measurement records that are linked to the KPI record).
- If the primary source record is an Xi Tag record, the graph displays a history of reading values that were collected by the process historian and stored in secondary source records, (i.e., Xi Reading records that are linked to the Xi Tag record).

About the Graph

The following image shows an example of the graph that is displayed on the **Trend** tab.




The y-axis displays numbers representing reading values. The x-axis displays dates and times, using a 24-hour clock. When you point to the line plotted on the graph, data-points appear that represent the readings taken at specific dates and times. For each datapoint, the exact reading value for that particular reading appears above the graph, on the left. The date on which the reading was taken also appears above the graph, on the right. The following image shows an example of a datapoint for a Health Indictor whose primary source record is a KPI record. In this example, the reading value that appears above the graph is *2.5*, indicating that on Tuesday, July 10, 2012, the time it took for a water heater to yield hot water was 2.5 minutes.



Below the graph, you will see another secondary graph with identical dates and times. This secondary graph allows you to shrink or expand the main graph to display only the portion that you want to see. When you pause on this secondary graph, your pointer appears as (\cdot) . You can drag the left or right border of the secondary graph to emphasize a given area, as shown in the following image.

	12:00	July 10	12:00	July 11	12:00
Data Range:	7/9/2012 0:00	▼ to 7/12/2012 0:00	Get		Zoom: 2D 10D 1M 1Y 3Y MAX

As you drag the secondary graph borders, the amount of data that appears in main graph area changes accordingly. In the following image, you can see that the right border of the secondary graph is positioned at the end of the day on July 10. The left border of the main graph, therefore, end at the end of the day on July 10.



You can right-click the main graph to see the following options:

- Show In Full Resolution: Displays the graph in high resolution.
- Show Limits (Primary Tag Only): Displays shaded areas on the graph that correspond to the status colors and limit values on <u>the gauges</u>. The following image shows an example of the Show Limits feature for a graph that displays readings for a KPI record where high values are good.




Below the graph itself, the following items appear:

- **Data range criteria**: Determines which readings are displayed on the graph.
- **Zoom buttons:** Let you control how much data you want to see on the graph.

About the Data Range Criteria

On the **Trend** tab, the data range criteria is displayed below the graph. The data range criteria is outlined in black in the following image.



When you access the **Trend** tab, the data range is set by default, based on the following criteria:

- If the primary source record for the Health Indicator record that is represented by the selected node is a Measurement Location record or a KPI record, all of the stored readings are displayed on the graph automatically.
- If the primary source record for the Health Indicator record that is represented by the selected node is an Xi Tag record, the readings for the previous *two days*will be displayed on the graph automatically as long as that number of readings does not exceed the limit of 10,000.

You can change the date and time in either date list and click the **Get** button to display the readings for that time period as they are stored in one of the following locations (depending upon the primary source record type)

- Reading records, if the primary source record is a Measurement Location record.
- KPI Measurement records, if the primary source record is a KPI record.
- A Process historian, if the primary source record is an Xi Tag record.

For example, if you wanted to view only the readings as they were stored in the KPI record *Time to Hot Water* from July 14, 2012 at 1:00 a.m. and July 15, 2012 at 12:00 p.m., you would select these dates and times in the **Data Range** lists, as shown in the following image.

Data Range:	7/14/2012 1:00	•	to	7/15/2012 12:00	-	Get	
-------------	----------------	---	----	-----------------	---	-----	--


In this case, after you clicked the **Get** button, the graph would be updated to display the readings that were collected during this time range, as shown in the following image.

Current Indicator enters Warning state.					
Details Trend St	ored Data Source				
Time to Hot Water Time to Hot Water Time to Hot Water Time to Hot Water Time Time Time Time Time Time Time Time	ater				
3.2					
3					
2.8					
2.6					
	July 14	12:00	18:00	July 15	06:00
	puly 14	12.00	10.00	puly 15	00.00
	12:00		July 14	12:00	
Data Danas 7/14		7/15/2012 12:00		_	
Data Range: 7/14/		7/15/2012 12:00	Get	200m: 2L	10D 1M 1Y 3Y MAX

Note that if you use the <u>Zoom buttons</u> to control the data that is displayed on the graph, the date range will be updated automatically to reflect the selected zoom option.

About the Zoom Buttons

On the **Trend** tab, the **Zoom** buttons are displayed below the graph. The **Zoom** buttons are outlined in black in the following image.



The following **Zoom** buttons are available:

- 2D: Displays the readings for the previous two days.
- 10D: Displays the readings for the previous ten days.
- 1M: Displays the readings for the previous one month.
- 1Y: Displays the readings for the previous one year.
- **3Y:** Displays the readings for the previous three years.
- MAX: Expands the boundaries of the graph to display all the readings that have been taken and stored in a record in the Meridium APM database.

Note: When the primary source record for the Health Indicator record that is represented by the selected node is an Xi Tag record, the maximum number of reading values that can be downloaded to the graph is 10,000 readings.

When you access the **Trend** tab:

- If the primary source record for the Health Indicator record that is represented by the selected node is a Measurement Location record or a KPI record, all of the stored readings are displayed on the graph automatically.
- If the primary source record for the Health Indicator record that is represented by the selected node is an Xi Tag record, the readings for the previous *ten years*will be displayed on the graph automatically as long as that number of readings does not exceed the limit of 10,000.

To display more or fewer readings, you can click the desired **Zoom** button. If you use the **Zoom** buttons to control the amount of data that is displayed on the graph, the data range will be updated automatically to reflect the selected zoom option.

Source Tab

The **Source** tab appears when a Health Indicator node is selected in the **Health Indicator Explorer** pane. This tab displays the datasheet of the primary source record of the Health Indicator record represented by the selected node.

Note: The datasheet that appears on the **Source** tab is read-only.

The following image shows an example of the **Source** tab as it appears on the **Asset Health Manager** page.

Asset Health Manager -	Plumbing System ~					
Health Indicator Explorer	Current Indicator enters Alert state.	A 1				
Plumbing System ~	Details Trend Stored Data Source					
PL-101 ~	Identification Limit Values					
WH101 ~ ~ Water Heater		1				
Condition Check ~ Describe	▶ Template	Value(s)				
	Asset ID	Water Heater				
Pressure Reading ~ Water H	Equipment Technical Number					
Ime to Hot Water ~ Amount	Asset Description					
	ML Description	Pressure Reading				
	ML Type	Numeric				
	Unit of Measure	Pounds/Sq Inch (PSI)				
	Category	Pressure Reading				
	Allowable Values					
	Maximum Valid Value					
	Minimum Valid Value					
	Maximum Target Value					
	Minimum Target Value					
	More Information					
	Status	Active				
	Sequence	02				
	Product					
	Bluetooth Measurement Type					
	Barcode ID					
Filters	Scan to Unlock?					
Add Delete						

Stored Data

The Stored Data tab appears when the following criteria are satisfied:

- A Health Indicator node is selected in the Health Indicator Explorer pane.
 - and -
- The corresponding Health Indicator record is linked to at least one record that contains reading values.

The **Stored Data** tab contains a grid that displays the following columns:

- **Reading Date:** The date and time of the reading as it is stored in the associated reading record.
- **Reading Value:** The reading value as stored in the associated reading record.
- **Status:** The status of the Health Indicator record based upon the reading value.

The following image shows an example of the **Stored Data** tab as it appears on the **Asset Health Manager** page.

Asset Health Manager -	Plumbing System ~		
Health Indicator Explorer	Current Indicator enters Alert state.		A A A A
Plumbing System ~	Details Trend Stored Data Source		
□·▲ PL-101 ~			
📄 📥 WH101 ~ 🛛 Water Heater	Reading Date	Reading Value	Status
OSIPIVMS\Temperature Ch	▶ 7/15/2012 12:00 AM	115	
Condition Check ~ Describe	7/14/2012 12:00 AM	105	•
···- Duration of Hot Water ~ Me	7/13/2012 12:00 AM	75	
Pressure Reading ~ Water H			
Time to Hot Water ~ Amount			

Snapshot Tab

The **Snapshot** tab appears when the following criteria are satisfied:

- A Health Indicator node is selected in the Health Indicator Explorer pane.
 - and -
- The primary source record to the corresponding Health Indicator record is an Xi Tag record.

The **Snapshot** tab captures readings at certain intervals based on the data that is collected by a process historian. These values are not necessarily stored in Xi Reading records. Instead, they provide a textual representation of the historical data that is available on the **Trend** tab for a Health Indicator whose primary source record is an Xi Tag record.

About the Events Tab

The **Events** tab displays event data for the Equipment or Functional Location record that is selected in the <u>Health Indicator Explorer pane</u>. Specifically, in the baseline Meridium APM database, the **Events** tab contains a grid that displays values that come from:

- The *Event Mappings* that are defined for the families that store the event data.
- The *source event records* themselves (i.e., the records that store the event data).

You can view data on the **Events** tab to monitor the condition of a piece of equipment or location or look for trends in the events. For example, you might look at the data on this tab to determine the number of times a piece of equipment was operating outside of normal operating conditions and for how long.

Health Indicator Explorer	Summary Policies R	ecommendations Event	s			
A NO.1 STEAM REHEATER ~ HXST 152 (VOSIPIVMS\Temperature Check ~ Measur Pressure Reading ~ Water Heater, interna	두 귀 는 실	t	ŀ			٩
•	Severity	Name	Description	Туре	Start	End
	0	CAL00000003		Calibration, W	5/1/2013 1:0	5/1/2013 1:0
	0	CAL0000003		Calibration, Di	5/1/2013 1:0	5/1/2013 1:0
	0	CAL0000003		Calibration, A	5/1/2013 1:0	5/1/2013 1:0
	0	CAL0000003		Calibration, A	5/1/2013 1:0	5/1/2013 1:0
	0	INSP-24	Profile RT on	API 653 Inter	5/1/2013 12:	
	0	<u>INSP-19</u>	100% Visual	API 510 Exter	5/1/2013 12:	
	0	INSP-23	Profile RT on	API 653 Exter	5/1/2013 12:	
	0	INSP-20	100% Visual	API 510 Inter	5/1/2013 12:	
	0	INSP-25	Profile RT ma	External PRD	5/1/2013 12:	
	0	INSP-22	100% Externa	API 570 Exter	5/1/2013 12:	
	0	INSP-21	100% Floor S	API 510 Inter	5/1/2013 12:	
	0	CAL0000003		Calibration, A	4/19/2013 1:	4/19/2013 1:
	1 READING	<u>WH-00001 ~</u>	READING	Work History	4/19/2013 11	4/19/2013 11
	0	INSP-17		General Inspe	4/19/2013 11	4/19/2013 1:
	0	EVENT PROD	HXST 152	Production Ev	4/19/2013 10	4/19/2013 11
	0	INSP-15		Full Inspection	4/19/2013 8:	4/19/2013 9:
	0	INSP-18		Bundle Inspec	4/19/2013 1:	4/19/2013 10
	0	INSP-16		Pressure Test	4/19/2013 12	4/19/2013 12
Filters						

The following image shows an example of what the **Events** tab looks like.

The **Events** tab contains a <u>grid that displays the event data</u> and a <u>Filter section</u> that can be used to filter the data that is displayed in the grid.

Grid

The grid on the <u>Events tab</u> displays event data that is associated with the Equipment or Functional Location record that is selected in the <u>Health Indicator Explorer pane</u>. Specifically, the grid displays information stored in <u>source event records</u> according to the Event Mappings that are defined for source event families. Each row in the grid represents one source event record.

A red outline has been added to the following image to highlight the grid on the **Events** tab.

th Indicator Explorer △	Summary Policies	Recommendations Ev	ents			
~ NO.1 STEAM REHEATER ~ HXST 152						٩
• · · · · · · · · · · · · · · · · · · ·	Severity	Name	Description	Туре	Start	End
	0	CAL0000000		Calibration,	5/1/2013 1:	5/1/2013 1:
	0	CAL0000000		Calibration,	5/1/2013 1:	5/1/2013 1:
	0	<u>CAL0000000</u>		Calibration,	5/1/2013 1:	5/1/2013 1:
	0	<u>CAL0000000</u>		Calibration,	5/1/2013 1:	5/1/2013 1:
	0	INSP-24	Profile RT on	API 653 Inte	5/1/2013 12	
	0	INSP-19	100% Visual	API 510 Exte	5/1/2013 12	
	0	INSP-23	Profile RT on	API 653 Exte	5/1/2013 12	
	0	INSP-20	100% Visual	API 510 Inte	5/1/2013 12	
	0	INSP-25	Profile RT m	External PRD	5/1/2013 12	
	0	INSP-22	100% Extern	API 570 Exte	5/1/2013 12	
	0	INSP-21	100% Floor	API 510 Inte	5/1/2013 12	
	0	<u>CAL0000000</u>		Calibration,	4/19/2013 1	4/19/2013 1
	1 READING	<u>WH-00001</u>	READING	Work History	4/19/2013 1	4/19/2013 1
	0	INSP-17		General Insp	4/19/2013 1	4/19/2013 1
	0	EVENT PROD	HXST 152	Production E	4/19/2013 1	4/19/2013 1
	0	INSP-15		Full Inspection	4/19/2013 8	4/19/2013 9
	0	INSP-18		Bundle Inspe	4/19/2013 1	4/19/2013 1
	0	INSP-16		Pressure Tes	4/19/2013 1	4/19/2013 1

The grid contains the following columns that display values in the source event records, according to the mappings that exist for the source event families:

- Severity
- Name
- Description
- Start
- End

The grid also contains the **Type** column, which displays the family caption of the source event family represented by the source event record in each row. Additionally, the grid contains the **Severity** column, which contains the combination of an <u>icon that cor</u>-responds with the event severity and a value that is stored in the source event record.

Above the grid to the right, an unlabeled text box containing the **Q** icon appears that you can use to filter the records in the grid according to values that are displayed in the **Name** and **Description** columns.

Above the grid to the left, the **button** is displayed, which can be used to <u>view the</u> **<u>Events</u>** tab in full screen mode.

Filter Section

Below the <u>grid</u> on the <u>Events tab</u>, an unlabeled, collapsible section appears that can be used to filter the data that is displayed in the grid. Throughout the documentation, we refer to this unlabeled section as the *Filter section*.

The Filter section is <u>collapsed</u> by default. A red outline has been added to the following image to highlight the collapsed Filter section.

NO. 1 STEAM REHEATER ~ HXST 152 (\OSIPIVMS\Temperature Check ~ Measure in Cel Pressure Reading ~ Water Heater, internal PSI	Severity					
	Severity					
		Name	Description	Туре	Start	End
	0	CAL0000000345		Calibration, Wei	5/1/2013 1:09:	5/1/2013 1:09:.
	0	CAL0000000344		Calibration, Disc	5/1/2013 1:09:	5/1/2013 1:09:.
	0	CAL0000000343		Calibration, Ana	5/1/2013 1:08:	5/1/2013 1:08:.
	0	CAL000000342		Calibration, Ana	5/1/2013 1:08:	5/1/2013 1:08:.
	0	INSP-24	Profile RT on th	API 653 Interna	5/1/2013 12:00	
	0	INSP-19	100% Visual Co	API 510 Externa	5/1/2013 12:00	
	0	INSP-23	Profile RT on th	API 653 Externa	5/1/2013 12:00	
	0	INSP-20	100% Visual Co	API 510 Interna	5/1/2013 12:00	
	0	INSP-25	Profile RT may	External PRD Ch	5/1/2013 12:00	
	0	INSP-22	100% External	API 570 Externa	5/1/2013 12:00	
	0	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013 12:00	
	0	CAL0000000321		Calibration, Ana	4/19/2013 1:37	4/19/2013 1:37
	1 READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013 11:2	4/19/2013 11:1
	0	INSP-17		General Inspect	4/19/2013 11:0	4/19/2013 1:00
	0	EVENT PROD	HXST 152	Production Event	4/19/2013 10:0	4/19/2013 11:0
	0	INSP-15		Full Inspection	4/19/2013 8:00	4/19/2013 9:00
	0	INSP-18		Bundle Inspection	4/19/2013 1:00	4/19/2013 10:0
	0	INSP-16		Pressure Test I	4/19/2013 12:0	4/19/2013 12:0

When you click the \uparrow button at the top of the Filter section, the section is <u>expanded</u>, and the \uparrow button changes to \checkmark . A red outline has been added to the following image to highlight the expanded Filter section.

ealth Indicator Explorer 🛛 🛆	Summary Policies Recor	mmendations Events					
▲ ~ NO.1 STEAM REHEATER ~ HXST 152	5.7						
\\OSIPIVMS\Temperature Check ~ Measure in Cel Pressure Reading ~ Water Heater, internal PSI							c
	Severity	Name	Description	Туре	Start		End
	0	CAL000000345		Calibration, Wei	5/1/2013 1	:09:	5/1/2013 1:09:
	0	CAL000000344		Calibration, Disc	5/1/2013 1	:09:	5/1/2013 1:09:
	0	CAL000000343		Calibration, Ana	5/1/2013 1	:08:	5/1/2013 1:08:
	0	CAL000000342		Calibration, Ana	5/1/2013	:08:	5/1/2013 1:08:
	0	INSP-24	Profile RT on th	API 653 Interna	5/1/2013 1	2:00	
	0	INSP-19	100% Visual Co	API 510 Externa	5/1/2013 1	2:00	
	0	INSP-23	Profile RT on th	API 653 Externa	5/1/2013 1	2:00	
	0	INSP-20	100% Visual Co	API 510 Interna	5/1/2013 1	2:00	
	0	INSP-25	Profile RT may	External PRD Ch	5/1/2013 1	2:00	
	0	INSP-22	100% External	API 570 Externa	5/1/2013 1	2:00	
	0	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013 1	2:00	
	0	CAL000000321		Calibration, Ana	4/19/2013	1:37	4/19/2013 1:37
	1 READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013	11:2	4/19/2013 11:1
	0	INSP-17		General Inspect	4/19/2013	11:0	4/19/2013 1:00
	0	EVENT PROD	HXST 152	Production Event	4/19/2013	10:0	4/19/2013 11:0
			events events		4/19/2013	10:0 Date R From 05/09 To	4/19/2013 11:0
Eilters		♥ Production ♥ Work Histo				Get	

The Filter section contains the following sub-sections:

- Severity: Displays check boxes that can be used to filter the data in the grid according to the event severity. The icon for each check box corresponds with the icon that is displayed in the Severity column for each event in the grid. When a check box is selected, events with the associated severity will be displayed in the grid. When a check box is cleared, events with the associated severity will be removed from the grid. The following check boxes are displayed in this sub-section:
 - Alert
 - Marning
 - Information
- **Type:** Displays a check box for each source event family that is represented in the grid. In the baseline Meridium APM database, the following check boxes are displayed in this sub-section:
 - Calibration events: When this check box is selected, data in records in Calibration subfamilies will be displayed in the grid. When this check box is

cleared, this data will be removed from the grid. You can click the button to the left of this check box to display one check box for each Calibration subfamily.

- Inspection events: When this check box is selected, data in records in the Inspection family and Inspection subfamilies will be displayed in the grid. When this check box is cleared, this data will be removed from the grid. You can click the button to the left of this check box to display one check box each for the Inspection family and certain Inspection subfamilies.
- Policy Event: When this check box is selected, data in Policy Event records will be displayed in the grid. When this check box is cleared, this data will be removed from the grid.
- Production Event: When this check box is selected, data in Production Event records will be displayed in the grid. When this check box is cleared, this data will be removed from the grid.
- Work History: When this check box is selected, data in Work History records will be displayed in the grid. When this check box is cleared, this data will be removed from the grid.

At the top of the **Type** sub-section, the **Select All** text box is displayed, which can be used to select and clear all of the check boxes in the **Type** sub-section. To the right of the **Select All** check box, the o button is displayed when you are logged in as a Super User or a member of the MI AHI Administrator Security Group. These users can click this button to access the **Event Mappings** window.

- **Date Range:** Displays the following items that are used to filter the data that is displayed in the grid according to the date that you specify:
 - From box: Displays a calendar that you can use to specify the beginning of the date range on which you want to filter the data in the grid. By default, this box contains a date that is one year earlier from the current date. For example, if the current date is 05/09/2013, this box contains the value 05/09/2012.
 - **To box:** Displays a calendar that you can use to specify the end of the date range on which you want to filter data in the grid. This box contains the current date by default.
 - **Get button:** Refreshes the grid to display data for events whose associated start date falls within the date range specified in the **From** and **To** boxes.

Viewing the Event Tab in Full Screen Mode

You can view the **Events** tab in full screen mode to view the contents of the tab on the entire screen. The following instructions assume that the **Events** tab is selected on the **Asset Health Manager** page.

To view the Event tab in full screen mode:

• At the top of the **Events** tab, click the 🚺 button.

The **Events** tab expands to full screen mode, and the 🚺 button changes to 👯.

21 际 21 社					
Severity	Name	Description	Туре	Start	End
Ð	<u>CAL000000345 ~</u>		Calibration, Weight Scale	5/1/2013 1:09:53 PM	5/1/2013 1:09:53 PM
0	CAL000000344 ~		Calibration, Discrete	5/1/2013 1:09:19 PM	5/1/2013 1:09:19 PM
0	CAL000000343 ~		Calibration, Analyzer Single	5/1/2013 1:08:49 PM	5/1/2013 1:08:49 PM
0	CAL000000342 ~		Calibration, Analyzer Multi-C	5/1/2013 1:08:25 PM	5/1/2013 1:08:25 PM
0	INSP-24	Profile RT on the inner pipe	API 653 Internal Checklist	5/1/2013 12:00:00 AM	
0	INSP-19	100% Visual Coverage of th	API 510 External Checklist	5/1/2013 12:00:00 AM	
0	INSP-23	Profile RT on the inner pipe	API 653 External Checklist	5/1/2013 12:00:00 AM	
0	INSP-20	100% Visual Coverage of th	API 510 Internal Exchanger	5/1/2013 12:00:00 AM	
9	INSP-25	Profile RT may be used for p	External PRD Checklist	5/1/2013 12:00:00 AM	
0	INSP-22	100% External Visual of the	API 570 External Checklist	5/1/2013 12:00:00 AM	
0	INSP-21	100% Floor Scan with 100%	API 510 Internal Checklist	5/1/2013 12:00:00 AM	
0	CAL000000321 ~		Calibration, Analog	4/19/2013 1:37:54 PM	4/19/2013 1:37:54 PM
1 READING	WH-00001 ~ READING ~ ~	READING	Work History	4/19/2013 11:26:02 AM	4/19/2013 11:18:23 AM
0	INSP-17		General Inspection	4/19/2013 11:00:00 AM	4/19/2013 1:00:00 PM
0	EVENT PROD	HXST 152	Production Event	4/19/2013 10:00:00 AM	4/19/2013 11:00:00 AM
0	INSP-15		Full Inspection	4/19/2013 8:00:00 AM	4/19/2013 9:00:00 AM
0	INSP-18		Bundle Inspection	4/19/2013 1:00:00 AM	4/19/2013 10:00:00 AM
A	INSP-16		Pressure Test Inspection	4/19/2013 12:00:00 AM	4/19/2013 12:00:00 AM
Severity	Туре			elect All 🧔 Date Rang	je
Alert	Type ► ☑ Calibration events		nspection events	From	je 112 10:58
🗹 🔷 Alert 🗹 🗛 Warning	Type Image: Wight of the second sec			From 05/13/20 To	12 10:58
Alert	Type ► ☑ Calibration events		nspection events	From 05/13/20	12 10:58
 ✓ Alert ✓ A warning 	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🔕 Alert 👿 🗚 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🔕 Alert 👿 🗚 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🔕 Alert 👿 🗚 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🔕 Alert 👿 🗚 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🔕 Alert 👽 🗚 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🗘 Alert 🗹 🗛 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58
🗹 🔷 Alert 🗹 🗛 Warning	Type Image: Wight of the second sec		nspection events	From 05/13/20 To	12 10:58

When you are viewing the **Events** tab in full screen mode, you can close the full screen mode to view the **Events** tab on the **Asset Health Manager** page.

To close the full screen mode:

• At the top of the **Events** tab, click the **##** button.

The full screen mode closes, the **Events** tab is displayed on the **Asset Health Manager** page, and the **##** changes to **##**.

	Summary Policies Record	Name CAL000000345 CAL000000344 CAL000000343 CAL000000342 INSP-24	Description	Calibration, Disc Calibration, Ana	5/1/2013 1:09	End : 5/1/2013 1:09: : 5/1/2013 1:09: : 5/1/2013 1:09:
 Print Send To >> Help Vesociated Pages Create Calibration >> Create Task Create Task Create Task 	 * # Severity O O<th>CAL000000345 CAL0000000344 CAL0000000343 CAL0000000342</th><th>Description</th><th>Calibration, Wei Calibration, Disc Calibration, Ana</th><th>5/1/2013 1:09 5/1/2013 1:09</th><th>End : 5/1/2013 1:09: : 5/1/2013 1:09:</th>	CAL000000345 CAL0000000344 CAL0000000343 CAL0000000342	Description	Calibration, Wei Calibration, Disc Calibration, Ana	5/1/2013 1:09 5/1/2013 1:09	End : 5/1/2013 1:09: : 5/1/2013 1:09:
Help Help Create Calibration >> Create Task Create Template >>	0 0 0 0	CAL000000345 CAL0000000344 CAL0000000343 CAL0000000342	Desciption	Calibration, Wei Calibration, Disc Calibration, Ana	5/1/2013 1:09 5/1/2013 1:09	: 5/1/2013 1:09: : 5/1/2013 1:09:
Create Calibration >> Create Task Create Template >>	0	CAL000000343 CAL0000000342		Calibration, Ana		
Create Task Create Template >>	0			Calibration, Ana		
		<u>1110P-24</u>	Drofile DT on th			: 5/1/2013 1:08:
	U	INSP-19		API 653 Interna API 510 Externa		
	0	INSP-23 INSP-20		API 653 Externa API 510 Interna		
	0	INSP-25 INSP-22		External PRD Ch API 570 Externa		
	0	INSP-21		API 510 Interna	5/1/2013 12:0	0
	1 READING	CAL000000321 WH-00001 ~ R	READING	Calibration, Ana Work History		7 4/19/2013 1:37 2 4/19/2013 11:1
	0	INSP-17 EVENT PROD	HXST 152			0 4/19/2013 1:00 0 4/19/2013 11:0
						:
	Severity C Alert A Warning C Information	Type Calibration Calibration For Inspection Policy Ever Production Work Histo	events t Event	✓ Select A	Fr 01 Tc	te Range 5/13/2012 10:58 5/13/2013 10:58 Set


Expanding and Collapsing the Filter Section

You can expand and collapse the <u>Filter section</u> on the <u>Events tab</u> depending on whether or not you want to see the content of the **Filter** section. The following instructions assume that the **Events** tab is selected on the **Asset Health Manager** page.

To expand the Filter section:

• At the top of the Filter section, click the 🗙 button.

The \land button changes to \lor , and the Filter section expands.



☆.

To collapse the Filter section:

• At the top of the Filter section, click the 😻 button.

The \bigotimes button changes to \bigwedge , and the Filter section collapses.

Filtering the Grid By Event Severity

You can filter the grid on the **Events** tab according to values in the **Name** and **Descrip**tion columns by typing in the <u>unlabeled text box above the grid</u>. Additionally, if you want to view events associated with a particular severity, you can filter the grid according to event severity. The following instructions assume that you are viewing the **Events** tab for the Equipment or Functional Location record whose event data you want to filter and the <u>Filter section is expanded</u>.

To filter the grid on the Events tab according to event severity:

• In the Filter section, in the **Severity** sub-section, select the check boxes associated with the event severities that you want to be displayed in the grid.

The grid is refreshed and displays event data according to your selections.

For example, in the following image, events associated with *Warning* and *Inform-ation* severities are displayed in the grid.

陈 朝 始 始						(۹
Severity	Name	Description	Туре	Start		End	
A	CAL000000345		Calibration, Wei	5/1/2013	1:09:	5/1/2013 1:09:	-
A	CAL000000344		Calibration, Disc	5/1/2013	1:09:	5/1/2013 1:09:	
A	CAL000000343		Calibration, Ana	5/1/2013	1:08:	5/1/2013 1:08:	
A	CAL000000342		Calibration, Ana	5/1/2013	1:08:	5/1/2013 1:08:	
9	INSP-24	Profile RT on th	API 653 Interna	5/1/2013	12:00		
9	INSP-19	100% Visual Co	API 510 Externa	5/1/2013	12:00		
)	INSP-23	Profile RT on th	API 653 Externa	5/1/2013	12:00		
	INSP-20	100% Visual Co	API 510 Interna	5/1/2013	12:00		
	INSP-25	Profile RT may	External PRD Ch	5/1/2013	12:00		
	INSP-22	100% External	API 570 Externa	5/1/2013	12:00		
	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013	12:00		
<u>.</u>	CAL000000321		Calibration, Ana	4/19/2013	3 1:37	4/19/2013 1:37	
READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013	3 11:2	4/19/2013 11:1	
	INSP-17		General Inspect	4/19/2013	3 11:0	4/19/2013 1:00	
	EVENT PROD	HXST 152	Production Event	4/19/2013	3 10:0	4/19/2013 11:0	
Geverity Calert Calert Cale A Warning Cale Cale Cale Cale Cale Cale Cale Cale Cale Cale Calert	Type Calibration Tinspection Policy Ever Production	events It	Select A	II Ö	То	ange)/2012 08:15)/2013 08:15	
	☑ Work Histor	ry					

Continuing with the example, the following image shows what the grid looks like when you specify that only events associated with *Information* severities should be displayed.

a			-	.			
Severity	Name	Description	Туре	Start		End	
0	INSP-24	Profile RT on th	API 653 Interna	5/1/2013	12:00		
0	INSP-19	100% Visual Co	API 510 Externa	5/1/2013	12:00		
0	INSP-23	Profile RT on th	API 653 Externa	5/1/2013	12:00		
0	INSP-20	100% Visual Co	API 510 Interna	5/1/2013	12:00		
0	INSP-25	Profile RT may	External PRD Ch	5/1/2013	12:00		
0	INSP-22	100% External	API 570 Externa	5/1/2013	12:00		
0	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013	12:00		
READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013	3 11:2	4/19/2013 11:	1
0	INSP-17		General Inspect	4/19/2013	3 11:0	4/19/2013 1:0	0
0	EVENT PROD	HXST 152	Production Event	4/19/2013	3 10:0	4/19/2013 11:	0
0	INSP-15		Full Inspection	4/19/2013	8:00	4/19/2013 9:0	0
_			Bundle Inspection	4/19/2013	3 1:00		
0	INSP-18						
0 0	INSP-18 INSP-16		Pressure Test I			4/19/2013 12:	0
0				4/19/2013			:0
0	INSP-16	events	Pressure Test I	4/19/2013	Date R	lange	:0
1 Severity	INSP-16		Pressure Test I	4/19/2013	Date R		:0
Severity	INSP-16 Type ► ♥ Calibration ► ♥ Inspection	events	Pressure Test I	4/19/2013	Date R From 05/10 To	lange	:0
Severity	Type V Calibration V Inspection	events nt	Pressure Test I	4/19/2013	Date R From 05/10 To	ange)/2012 08:15	:0
Severity	Type V Calibration V Inspection Policy Ever	events ht Event	Pressure Test I	4/19/2013	Date R From 05/10 05/10	ange)/2012 08:15	:0
Severity Content Alert Available	INSP-16 Type V Calibration V Inspection V Policy Ever V Production	events ht Event	Pressure Test I	4/19/2013	Date R From 05/10 05/10	ange)/2012 08:15	:0
Severity Alert Avarning	INSP-16 Type V Calibration V Inspection V Policy Ever V Production	events ht Event	Pressure Test I	4/19/2013	Date R From 05/10 05/10	ange)/2012 08:15	:0

Filtering the Grid By Event Type

You can filter the grid on the **Events** tab according to values in the **Name** and **Descrip**tion columns by typing in the <u>unlabeled text box above the grid</u>. Additionally, if you want to view only certain types of events associated with an Equipment or Functional Location record, you can filter the grid according to event type. The following instructions assume that you are viewing the **Events** tab for the Equipment or Functional Location record whose event data you want to filter and the Filter section is expanded.

To filter the grid on the Events tab according to event type:

• In the Filter section, in the **Type** sub-section, select the check boxes associated with the types of events that you want to be displayed in the grid.

The grid is refreshed and displays event data according to your selections.

For example, in the following image, *all* event types are displayed in the grid.

陈 朝 始 加				l			٩
Severity	Name	Description	Туре	Start		End	
0	CAL000000345		Calibration, Wei	5/1/2013	1:09:	5/1/2013 1:09:	,
0	CAL000000344		Calibration, Disc	5/1/2013	1:09:	5/1/2013 1:09:	
0	CAL000000343		Calibration, Ana	5/1/2013	1:08:	5/1/2013 1:08:	,
0	CAL000000342		Calibration, Ana	5/1/2013	1:08:	5/1/2013 1:08:	,
D	INSP-24	Profile RT on th	API 653 Interna	5/1/2013	12:00		
0	INSP-19	100% Visual Co	API 510 Externa	5/1/2013	12:00		
0	INSP-23	Profile RT on th	API 653 Externa	5/1/2013	12:00		
0	INSP-20	100% Visual Co	API 510 Interna	5/1/2013	12:00		
0	INSP-25	Profile RT may	External PRD Ch	5/1/2013	12:00		
0	INSP-22	100% External	API 570 Externa	5/1/2013	12:00		
0	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013	12:00		
0	CAL000000321		Calibration, Ana	4/19/2013	3 1:37	4/19/2013 1:37	
READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013	3 11:2	4/19/2013 11:1	
0	INSP-17		General Inspect	4/19/2013	3 11:0	4/19/2013 1:00	
0	EVENT PROD	HXST 152	Production Event	4/19/2013	3 10:0	4/19/2013 11:0	
Severity C Alert A Warning () Information	 Type Calibration Inspection Policy Even Production Work Histor 	events It Event	☑ Select A	JI 🔅 —	То	ange)/2012 08:15)/2013 08:15	

Continuing with the example, the following image shows what the grid looks like when you specify that data associated with all types of events *except* Calibration events should be displayed in the grid.

Severity	Name	Description	Туре	Start	End	
0	INSP-24	Profile RT on th	API 653 Interna	5/1/2013 12	:00	
0	INSP-19	100% Visual Co	API 510 Externa	5/1/2013 12	:00	
0	INSP-23	Profile RT on th	API 653 Externa	5/1/2013 12	:00	
0	INSP-20	100% Visual Co	API 510 Interna	5/1/2013 12	:00	
0	INSP-25	Profile RT may	External PRD Ch	5/1/2013 12	:00	
0	INSP-22	100% External	API 570 Externa	5/1/2013 12	:00	
0	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013 12	:00	
1 READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013 1	1:2 4/19/2013 11:1.	
0	INSP-17		General Inspect	4/19/2013 1	1:0 4/19/2013 1:00.	
0	EVENT PROD	HXST 152	Production Event	4/19/2013 1	0:0 4/19/2013 11:0.	
0	INSP-15		Full Inspection	4/19/2013 8	:00 4/19/2013 9:00.	
0	INSP-18		Bundle Inspection	4/19/2013 1	:00	
0	<u>INSP-16</u>		Pressure Test I	4/19/2013 1	2:0 4/19/2013 12:0.	
	INSP-16				2:0 4/19/2013 12:0. Date Range	
		events	Pressure Test I	VII 🔅 — 🔽	Date Range	
Severity	Type Calibration			VII 🗘 — 🗆	Date Range From 05/10/2012 08:15	
	Type Calibration Inspection	events		NI Ø	Date Range	
Severity © Olert © Avarning	Type Calibration Inspection Policy Ever	events		NI Ø	Date Range From 05/10/2012 08:15 To	
Severity © Olert © Avarning	Type Calibration Inspection Policy Ever Production	events ht Event		NI Ø	Date Range From 05/10/2012 08:15 To 05/10/2013 08:15	
Severity © Otert © Alert © Awarning	Type Calibration Solution Policy Ever	events ht Event		NI Ø	Date Range From 05/10/2012 08:15 To 05/10/2013 08:15	
Severity V OAlert V Awarning	Type Calibration Inspection Policy Ever Production	events ht Event		NI Ø	Date Range From 05/10/2012 08:15 To 05/10/2013 08:15	
Severity V OAlert V Awarning	Type Calibration Inspection Policy Ever Production	events ht Event		NI Ø	Date Range From 05/10/2012 08:15 To 05/10/2013 08:15	

Filtering Event Data by Date

You can filter the grid on the **Events** tab according to values in the **Name** and **Descrip**tion columns by typing in the <u>unlabeled text box above the grid</u>. Additionally, if you want to view events associated with a particular date range, you can filter the grid according to date. The following instructions assume that you are viewing the **Events** tab for the Equipment or Functional Location record whose event data you want to filter and the <u>Filter section is expanded</u>.

To filter the grid on the Events tab according to date:

- 1. In the **Filter** section, in the **Date Range** sub-section, click in the **From** box, and use the calendar to specify the date that represents the beginning of the date range on which you want to filter data in the grid.
- 2. Click in the **To** box, and use the calendar to specify the date that represents the end of the date range on which you want to filter data in the grid.
- 3. Click the **Get** button.

The grid is refreshed to display data for events whose associated start date falls within the specified date range.

For example, the following image shows an example of the grid when the following values have been specified in the **From** and **To** boxes:

- From: 05/10/2012 08:15
- To: 05/10/2013 08:15

序 初 社 11						(٩
Severity	Name	Description	Туре	Start		End	
0	CAL000000345		Calibration, Wei	5/1/2013	1:09:	5/1/2013 1:09:	^
0	CAL000000344		Calibration, Disc	5/1/2013	1:09:	5/1/2013 1:09:	
0	CAL000000343		Calibration, Ana	5/1/2013	1:08:	5/1/2013 1:08:	
0	CAL000000342		Calibration, Ana	5/1/2013	1:08:	5/1/2013 1:08:	
0	INSP-24	Profile RT on th	API 653 Interna	5/1/2013	12:00		
0	INSP-19	100% Visual Co	API 510 Externa	5/1/2013	12:00		
0	INSP-23	Profile RT on th	API 653 Externa	5/1/2013	12:00		Ε
0	INSP-20	100% Visual Co	API 510 Interna	5/1/2013	12:00		
0	INSP-25	Profile RT may	External PRD Ch	5/1/2013	12:00		
0	INSP-22	100% External	API 570 Externa	5/1/2013	12:00		
0	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013	12:00		
0	CAL000000321		Calibration, Ana	4/19/2013	3 1:37	4/19/2013 1:37	
1 READING	<u>WH-00001 ~ R</u>	READING	Work History	4/19/2013	3 11:2	4/19/2013 11:1	
0	INSP-17		General Inspect	4/19/2013	3 11:0	4/19/2013 1:00	
0	EVENT PROD	HXST 152	Production Event	4/19/2013	3 10:0	4/19/2013 11:0	Ŧ
Severity	Type Calibration Tinspection Policy Even Production Work Histor	events t Event	☑ Select A	II Ö	То	ange /2012 08:15 /2013 08:15	~

Continuing with the example, the following image shows what the grid looks like when the following values have been specified in the **From** and **To** boxes:

- From: 04/21/2013 08:15
- To: 05/10/2013 08:15

Severity	Name	Description	Туре	Start		End	
1		Description			1.00.		
-	CAL000000345		Calibration, Wei				
0	CAL000000344		Calibration, Disc				
0	CAL000000343		Calibration, Ana			5/1/2013 1:08:	
0	CAL000000342		Calibration, Ana			5/1/2013 1:08:	
0	INSP-24	Profile RT on th	API 653 Interna				
0	INSP-19	100% Visual Co	API 510 Externa				
0	INSP-23	Profile RT on th	API 653 Externa				
0	INSP-20	100% Visual Co	API 510 Interna				
0	INSP-25	Profile RT may	External PRD Ch				
	THICD DO	1000/ Eutermed	API 570 Externa	F/1/2012	10.00		
	INSP-22 INSP-21	100% External 100% Floor Sca	API 510 Interna				
0							
Severity				5/1/2013	12:00	ange	
Severity Severity	INSP-21	100% Floor Sca	API 510 Interna	5/1/2013	Date R	_	
Severity	INSP-21 Type	100% Floor Sca	API 510 Interna	5/1/2013	Date R From 04/21 To	/2013 08:15	
Severity Severity	INSP-21 Type	100% Floor Sca events events	API 510 Interna	5/1/2013	Date R From 04/21 To 05/21	_	
Severity Content Co	INSP-21 Type Calibration Inspection	100% Floor Sca events events it	API 510 Interna	5/1/2013	Date R From 04/21 To	/2013 08:15	
Severity Content Co	INSP-21 Type Calibration Inspection Policy Even	100% Floor Sca events events it Event	API 510 Interna	5/1/2013	Date R From 04/21 To 05/21	/2013 08:15	
Severity Content Co	INSP-21 Type Calibration Inspection Policy Even Production	100% Floor Sca events events it Event	API 510 Interna	5/1/2013	Date R From 04/21 To 05/21	/2013 08:15	
Severity Content Co	INSP-21 Type Calibration Inspection Policy Even Production	100% Floor Sca events events it Event	API 510 Interna	5/1/2013	Date R From 04/21 To 05/21	/2013 08:15	

About Health Indicator Statuses

The status of a Health Indicator record is based upon values that are stored in the Health Indicator record and the primary source record to which the Health Indicator record is linked.

The status of a Health Indicator is determined differently, depending on the primary source record type, which can be:

- <u>A Measurement Location record that accepts numeric values</u>.
- A Measurement Location record that accepts character values.
- <u>A KPI record where a low value is good</u>.
- <u>A KPI record where a high value is good</u>.
- An Xi Tag record that accepts numeric values.
- An Xi Tag record that accepts character values.

The status of the Health Indicator record is stored as a number in the Alert Level field in the Health Indicator family. If the *Meridium.AHI.Service.exe.config* file has been <u>configured</u> properly, this value is updated automatically by the AHM Service.

- Health Indicator records that meet *Normal* status criteria contain the number *zero* (0) in the Alert Level field.
- Health Indicator records that meet *Warning* status criteria contain the number 1 in the Alert Level field.
- Health Indicator records that meet *Alert* status criteria contain the number 2 in the Alert Level field.

Each status is associated with a color, which you will see in the <u>Health Indicator Explorer</u> pane and in gauges that represent a range of acceptable values.

Statuses of Health Indicators Based on Numeric Measurement Locations

If a Health Indicator record is linked to a Measurement Location record that accepts numeric values, its status is determined based upon the two following things:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The limit values in the Measurement Location record (which are displayed on the Limit Values tab on the Measurement Location datasheet).

Note: Readings with a non-compliant status do not have a corresponding Health Indicator status and do not affect the Alert status shown in the **Health Indicator Explorer** pane.

The Health Indicator record is classified as meeting one of the following status criteria:

- Normal: The reading value falls between the values in the Lower Level 1 and Upper Level 1 fields. Health Indicator records that meet the Normal status criteria are represented by a green circle.
- Warning: The reading value meets either of the following conditions:
 - The reading value is less than or equal to the value in the Lower Level 1 field and greater than the value in the Lower Level 2 field.
 -or-
 - The reading value is greater than or equal to the value in the Upper Level 1 field and less than the value in the Upper Level 2 field.

Health Indicator records that meet the Warning status criteria are represented by a yellow circle.

- Alert: The reading value meets either of the following conditions:
 - The reading value is less than or equal to the value in the Lower Level 2 field.
 - The reading value is greater than or equal to the value in the Upper Level 2 field.

Health Indicator records that meet the Alert status criteria are represented by a red circle.

For example, consider the following Measurement Location limit values:

- Upper Level 3 = 140
- Upper Level 2 = 130
- Upper Level 1 = 120
- Lower Level 1 = 110

- Lower Level 2 = 100
- Lower Level 3 = 90

- Alert = Any reading value greater than or equal to 130 (130 and above)
- **Warning** = Any reading value greater than or equal to 120 and less than 130 (120 129)
- Normal = Any reading value greater than 110 and less than 120 (111 119)
- **Warning** = Any reading value less than or equal to 110 and greater than 100 (101 110)
- Alert = Any reading value less than 100 (100 and below)

Statuses of Health Indicators Based on Character Measurement Locations

If a Health Indicator record is linked to a Measurement Location record that accepts character values, its status is determined based upon the two following things:

- The value stored in the Last Char Reading Value field in the Health Indicator record.
- The limit values in the Measurement Location record (which are displayed on the Limit Values tab on the Measurement Location datasheet).

Note: Readings with a non-compliant status do not have a corresponding Health Indicator status and do not affect the Alert status shown in the **Health Indicator Explorer** pane.

The Health Indicator record is classified as meeting one of the following status criteria:

- Normal: The reading value does not appear on the Limit Values tab. Health Indicator records that meet the Normal status criteria are represented by a green circle.
- Warning: The reading value appears on the Limit Values tab in either the Lower Level 1 or Upper Level 1 cells. Health Indicator records that meet the Warning status criteria are represented by a yellow circle.
- Alert: The reading value appears on the Limit Values tab in the Lower Level 2, Upper Level 2, Lower Level 3, or Upper Level 3 cells. Health Indicator records that meet the Alert status criteria are represented by a red circle.

Statuses of Health Indicators Based on KPIs Where Low Values are Good

If a Health Indicator record is linked to a KPI record, its status is determined based upon the two following things:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The Target and Critical values that are stored in the most recent KPI Measurement record that is linked to the KPI record.

Note: Because these limit values are stored in secondary source records (i.e., KPI Measurement records), they are not displayed on the KPI datasheet. Instead, you can view these values by opening the most recent KPI Measurement record in Record Manager.

The Health Indicator record is classified as meeting one of the following status criteria:

- **Normal:** The value stored in the Last Numeric Reading Value field is less than the Target value. Health Indicator records that meet the Normal status criteria are represented by a green circle.
- **Warning:** The value stored in the Last Numeric Reading Value field is greater than or equal to the Target value and less than the Critical value. Health Indicator records that meet the Warning status criteria are represented by a yellow circle.
- Alert: The value stored in the Last Numeric Reading Value field is greater than or equal to the Critical value. Health Indicator records that meet the Alert status criteria are represented by a red circle.

For example, consider the following KPI Measurement values:

- Target = 5
- Critical = 10

- Normal = Any measurement value less than 5 (4 and below)
- **Warning** = Any measurement value greater than or equal to 5 and less than 10 (5 9)
- Alert = Any measurement value greater than or equal to 10 (10 and above)

Statuses of Health Indicators Based on KPIs Where High Values are Good

If a Health Indicator record is linked to a KPI record, its status is determined based upon the two following things:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The Target and Critical values that are stored in the most recent KPI Measurement record that is linked to the KPI record.

Note: Because these limit values are stored in secondary source records (i.e., KPI Measurement records), they are not displayed on the KPI datasheet. Instead, you can view these values by opening the most recent KPI Measurement record in Record Manager.

The Health Indicator record is classified as meeting of the following status criteria:

- Normal: The value stored in the Last Numeric Reading Value field is greater than the Target value. Health Indicator records that meet the Normal status criteria are represented by a green circle.
- **Warning:** The value stored in the Last Numeric Reading Value field is less than or equal to the Target value and greater than the Critical value. Health Indicator records that meet the Warning status criteria are represented by a yellow circle.
- Alert: The value stored in the Last Numeric Reading Value field is less than or equal to the Critical value. Health Indicator records that meet the Alert status criteria are represented by a red circle.

For example, consider the following KPI Measurement values:

- Target = 10
- Critical = 5

- Normal = Any measurement value greater than 10 (11 and above)
- **Warning** = Any measurement value less than or equal to 10 and greater than 5 (6 10)
- Alert = Any measurement value less than or equal to 5 (5 and below)

Statuses of Health Indicators Based on Numeric Xi Tags

If a Health Indicator record is linked to an Xi Tag record that accepts numeric values, its status is determined based upon two things:

- The value stored in the Last Numeric Reading Value field in the Health Indicator record.
- The limit values in the Xi Tag record (which are displayed on the Limit Values tab on the Xi Tag datasheet).

The Health Indicator record is classified as meeting one of the following status criteria:

- Normal: The reading value falls between the values in the Numeric Lower Level 1 and Numeric Upper Level 1 fields. Health Indicator records that meet the Normal status criteria are represented by a green circle.
- Warning: The reading value meets either of the following conditions:
 - The reading value is less than or equal to the value in the Numeric Lower Level 1 field and greater than the value in the Numeric Lower Level 2 field. -or-

The reading value is greater than or equal to the value in the Numeric Upper Level 1 field and less than the value in the Numeric Upper Level 2 field.

Health Indicator records that meet the Warning status criteria are represented by a yellow circle.

- Alert: The reading value meets either of the following conditions:
 - The reading value is less than or equal to the value in the Numeric Lower Level 2 field.
 - The reading value is greater than or equal to the value in the Numeric Upper Level 2 field.

Health Indicator records that meet the Alert status criteria are represented by a red circle.

For example, consider the following Xi Tag limit values:

- Numeric Upper Level 3 = 140
- Numeric Upper Level 2 = 130
- Numeric Upper Level 1 = 120
- Numeric Lower Level 1 = 110
- Numeric Lower Level 2 = 100
- Numeric Lower Level 3 = 90

- Alert = Any reading value greater than or equal to 130 (130 and above)
- **Warning** = Any reading value greater than or equal to 120 and less than 130 (120 129)
- Normal = Any reading value greater than 110 and less than 120 (111 119)
- **Warning** = Any reading value less than or equal to 110 and greater than 100 (101 110)
- Alert = Any reading value less than 100 (100 and below)

Statuses of Health Indicators Based on Character Xi Tags

If a Health Indicator record is linked to an Xi Tag record that accepts character values, its status is determined based upon two things:

- The value stored in the Last Char Reading Value field in the Health Indicator record.
- The limit values in the Xi Tag record (which are displayed on the Limit Values tab on the Xi Tag datasheet).

The Health Indicator record is classified as meeting one of the following status criteria:

- Normal: The reading value does not appear on the Limit Values tab. Health Indicator records that meet the Normal status criteria are represented by a green circle.
- Warning: The reading value appears on the Limit Values tab in either the Character Lower Level 1 or Character Upper Level 1 cells. Health Indicator records that meet the Warning status criteria are represented by a yellow circle.
- Alert: The reading value appears on the Limit Values tab in the Character Lower Level 2, Character Upper Level 2, Character Lower Level 3, or Character Upper Level 3 cells. Health Indicator records that meet the Alert status criteria are represented by a red circle.

Acknowledging a Single Health Indicator Record's Status

If a Health Indicator record meets Warning or Alert status, you can acknowledge the status, which will change it to Normal. The following instructions provide details on acknowledging a single Health Indicator status. You can also <u>acknowledge multiple</u> <u>Health Indicator records' statuses at once</u>.

To acknowledge a single Health Indicator record's status:

- 1. On the **Asset Health Manager** page, in the <u>Health Indicator Explorer pane</u>, select the Health Indicator node representing the record whose status you want to acknowledge.
- 2. To the right of the **Health Indicator Explorer** pane, on any tab, click the *but-* ton.

Acknowledgement Note		_ • •
Acknowledger	nent Note	
◯ Valid Until	 One Time Acknowledgement 	-
		OK Cancel

The Acknowledge Note window appears.

- 3. In the text area, type your comments.
- 4. If you want the acknowledgement to remain valid only until a new reading is taken, click **OK**.

- or -

If you want to set an expiration date for the acknowledgement:

a. Select the Valid Until option.

The **Expiration Date** list appears, as shown in the following image. A red outline has been added to the image to highlight this area.

Acknowledgement Note		
Acknowledgement Note		
Acknowledging Pressure Reading, Alert status		
Valid Until One Time Acknowledgement		
Expiration Date: 7/16/2012		
	ОК	Cancel

b. In the **Expiration Date** list, select an expiration date from the calendar, and click **OK**.

The status indicator of the Health Indicator node changes to include a check mark inside the circle (e.g., \bigcirc), and the \checkmark button is replaced by the \checkmark button, which you can use to revoke the acknowledgement at any time.

In addition, beside the 🔚 button, the 🛐 button becomes enabled. You can

click this button to view and modify the contents of the **Acknowledgement Note** window.

Note: Acknowledged, Acknowledgement Note, Acknowledged By, and Acknowledged Date are fields on the Health Indicator family. If desired, you can include them in a query that returns Health Indicator records.

Acknowledging Multiple Health Indicator Records' Statuses

If multiple Health Indicator records meet Warning or Alert status, you can acknowledge their statuses all at once, which will change them all to Normal. The following instructions provide details on acknowledging the statuses of multiple Health Indicator records at once. You can also <u>acknowledge an individual Health Indicator record status</u>.

To acknowledge multiple Health Indicator record's statuses:

- 1. On the **Asset Health Manager** page, in the **Health Indicator Explorer**pane, select the Equipment node.
- 2. On the **Summary** tab, for the Health Indicator records whose statuses you want to acknowledge, select the check box to the left of the Health Indicator Record ID.

- or -

On the **Summary** tab, above the gauges, select the **All** check box.

A status message and the following buttons appear above the Asset Health gauges.

- 😺 :Lets you acknowledge the status.
- Elets you create a Meridium General Recommendation record, which will be linked to the Health Indicator records you select.
- 3. Click the 🧈 button.

The Acknowledgement Note window appears.

Acknowledgement Note		
Acknowledgeme	nt Note	
		▲ ▼
💿 Valid Until	One Time Acknowledgement	
		OK Cancel

- 4. In the text area, type your comments.
- 5. If you want the acknowledgement to remain valid only until a new reading is taken, click **OK**.

- or -

If you want to set an expiration date for the acknowledgement:

a. Select the Valid Until option.

The **Expiration Date** list appears, as shown in the following image. A red outline has been added to the image to highlight this area.

Acknowledgement Note	
Acknowledgement Note	
Acknowledging all Health Indicators with statuses of Alert	
Valid Until One Time Acknowledgement	
Expiration Date: 7/16/2012	Cancel

b. In the **Expiration Date** list, select an expiration date from the calendar, and click OK.

For each Health Indicator record whose status you acknowledged, the status indicator of the Health Indicator node changes to include a check mark inside the circle (e.g.,
and a green check mark appears to the left of the associated gauge.

Unless you <u>revoke an acknowledgement</u>, it will remain valid until the expiration date or a reading is taken that satisfies Normal status criteria, depending on your selection in step 5.

Note: Acknowledged, Acknowledgement Note, Acknowledged By, and Acknowledged Date are fields on the Health Indicator family. If desired, you can include them in a query that returns Health Indicator records.

Revoking the Acknowledgement of a Health Indicator Record's Status

Regardless of whether you acknowledged a Health Indicator record's status individually or as part of a group of Health Indicator records, if you want to revoke the acknowledgement, you must do so for each individual Health Indicator record whose status has been acknowledged.

To revoke the acknowledgement of a Health Indicator record's status:

- On the <u>Asset Health Manager page</u>, in the <u>Health Indicator Explorer pane</u>, select the Health Indicator node representing the record whose acknowledgement you want to revoke.
- 2. Click the 🔏 button.

A confirmation message appears asking if you are sure you want to revoke the acknowledgement.

3. Click the **Yes** button.

The status of the Health Indicator record returns to either *Warning* or *Alert*, and the green check mark (e.g., \checkmark) that was displayed beside the associated gauge on the <u>Summary tab</u> is replaced with a check box.

Creating Health Indicator Records via the Asset Health Manager Page

Note: You can create a Health Indicator record only if you are a member of the MI AHI Administrator Security Group.

To create a Health Indicator record:

1. On the <u>Asset Health Manager page</u>, below the Health Indicator Explorer pane, click the Add button.

The Health Indicator Builder appears, displaying the Welcome screen.

😸 Health Indicator Builder	- Welcome	
meridium	Welcome to the Health Indicator Builder	
	This is where you create a new Health Indicator.	
	Don't show this page again.	
	To continue, click Next.	
	< Back Next > Finish Cancel	Help

2. Click the **Next** button.

The Select Source Type screen appears.

purce Type		
Family ID	Mapping Type	Description
▶ KPI	Numeric	KPI Mapping A - High Is Good
KPI	Numeric	KPI Mapping B - Low Is Good
Measurement Location	Character	Character Mapping for Measurement Locat.
Measurement Location	Numeric	Numeric Mapping for Measurement Location
Xi Tag	Character	Character mapping for Xi Tag
Xi Tag	Numeric	Numeric mapping for Xi Tag

- 3. In the grid in the **Source Type** section, select the row representing the type of primary source record to which you want to link the Health Indicator record.
- 4. Click the **Next** button.

The **Select Source Record** screen appears, displaying a list of records that meet criteria for the primary source record type that you selected in the previous screen. Note that if you have already created a Health Indicator from a record, that record

lea	lth Indicator	Builder - Sele	ect Source Record					
		Decord						
ele	ct Source	Record						
	Entity ID		Family	Description	Related Asset Id	Asset Description	ML Type	Cate 📤
►	~Water Heater	 Condition Check 	Measurement Location	Condition Check	Water Heater		Character	Conc
								-
•								•
ag,	e: 1 of	1 1 record	s found «	« First « Previou	s Next » La	ist »» Pa	ge Size: 10	00
				< Back	Next >	Finish C	ancel	Help

will not be displayed in the list.

- 5. Select the rows containing the records that you want to link to the new Health Indicator record.
- 6. Click the **Finish** button.

The **Health Indicator Builder** closes, and a node representing the new Health Indicator record appears in the <u>Health Indicator Explorer pane</u> below the root record. In addition, the new Health Indicator record is linked to the primary source records that you selected in the **Health Indicator Builder**.

Note: The Health Indicator name is determined using the <u>Health Indicator</u> <u>Mapping record</u> that was used to create the Health Indicator record.

Creating Health Indicator Records from the AHM Start Page

Note: You can create Health Indicator records only if you are a member of the MI AHI Administrator Security Group.

The following instructions provide details on creating multiple Health Indicator records from the <u>AHM Start Page</u>. Additionally, these instructions assume that you want to create Health Indicator records using one or both of the following types of primary source records:

- Measurement Location records
- Xi Tag records


You can <u>add additional Health Indicator records individually via the Asset Health Man-ager page</u>.

Note: If you want to create a Health Indicator record whose primary source record is a KPI record, you will need to do so from the **Asset Health Manager** page.

To create Health Indicator records from the AHM Start Page:

- 1. Access the AHM Start Page.
- 2. In the Links section, click the Create New Health Indicators for Assets link.

The Mass Health Indicator Builder appears, displaying the Welcome screen.



3. Click the **Next** button.

The Select Source Types to Create New Health Indicators against screen appears.

Mass Health Indicator	Builder	_			- • •
Select Source	Types to Cre	ate New Hea	th Indicators	against	
	Measurement Loca	ation			
	Xi Tags				
	j Ai Tays				
	< Back	Next >	Finish	Cancel	Halp
	< васк	Next >	Finish	Cancer	Help

- 4. If you want to create Health Indicator records from Measurement Location records, select the **Measurement Location** check box.
- 5. If you also want to create Health Indicator records from Xi Tag records, select the Xi Tags check box.

The Select Assets to Create Health Indicators for screen appears.

der	_	_	_	_	
Create Hea	lth Indicato	ors for			
n:			-	Find	Now
or:				St	op
Match Case	:?			New	Search
< Back	Next >	Finish		Cancel	Help
	i n:	Create Health Indicato	Create Health Indicators for	Create Health Indicators for	Create Health Indicators for

6. In the **Search In** list, select the **Equipment** family, and click the **Find Now** button.

The search results appears in a grid on the screen.

7. Select from the results grid the Equipment records to which you want to link the new Health Indicator records, and click the **Next** button.

The **Summary** screen appears, displaying the Equipment records you selected in the previous step and the primary source records to which they are linked.

ass Health Indicator Builder					
Summary					
Health Indicators being Created: 2	1				
Selected Assets					
Source					
Asset: ~ AIR AFTERCO	00LER (C-454) ~ H	XST 141			
\\OSIPIVM\CDT158					
Asset: ~ AIR AFTERCO	00LER (C-454) ~ H	XST 153			
Z_TRANDEP_Xi_Tag					
	< Back	Next >	Finish	Cancel	Help

8. Click the **Finish** button.

The **Creating Health Indicator** window appears, displaying the progress of the creation process. Once the Meridium APM system has completed this process, the **Creating Health Indicators** window is refreshed, and the **Close** button appears, as shown in the following image.

Creating Health Indicators			—
Created 1 of 1			
Ignore Errors			Close
Asset 🛆			
Health Indicator	Source	Status	
- Asset: E0013-064 ~ 00000000000	032850 ~ EXCHANGER - PREFLASH NAPT	HA COOLER ~	Shell and Tube Heat Exch
Cooler Backwash	00000000001032850 E0013-064 ~ Coole	Created	

9. Click the **Close** button.

The Health Indicator records are created and linked to the selected Equipment records, and the **AHM Start Page** returns to focus. To view the new Health Indicator records, you can <u>access the **Asset Health Manager** page</u> for those Equipment records.

About Creating Health Indicator Records via Policy Manager

Via the Policy Manage module, you can create a Health Indicator record whose:

- Primary source record is another Health Indicator record.
- Secondary source record is a Health Indicator Value record.

Changing the Name or Description of a Health Indicator Record

To change the name or description of a Health Indicator record:

- 1. On the <u>Asset Health Manager page</u>, in the <u>Health Indicator Explorer pane</u>, select the Health Indicator node representing the record whose name or description you want to change.
- 2. Select the **Details** tab.
- 3. To change the *name* of the Health Indicator record, in the **Name** text box, type the desired name.
- 4. To change the *description*, in the **Description** text box, type the desired description.

Your changes are saved automatically and applied to the Health Indicator record.

Creating a Recommendation Record Based Upon a Single Health Indicator

As you review the information for a Health Indicator record, you might want to recommend that some action be taken against the associated piece of equipment.

For example, suppose the Health Indicator record is linked to a Measurement Location record that is linked to a *Water Heater* Equipment record. Suppose that the Measurement Location record is also linked to Reading records whose values indicate that the water in the water heater has been losing heat. The historical values will be represented on the **Trend** tab. Based upon these values, you might want to create a Meridium General Recommendation record that recommends that an insulation blanket be purchased to insulate the water heater and prevent heat loss.

The following instructions provide details about creating a Meridium General Recommendation record based upon the data in a single Health Indicator record and assume that you are viewing the <u>Asset Health Manager page</u> for its associated Equipment record. You can also <u>create a Meridium General Recommendation record that is based</u> upon data in multiple Health Indicator records.

To create a Meridium General Recommendation record based upon data in a single Health Indicator record:

- 1. In the **Health Indicator Explorer** pane, select the Health Indicator node representing the record that you want to use as the basis for creating a Meridium General Recommendation record.
- 2. On the **Summary** tab, click the 🛃 button.

The **<Recommendation ID> (new Meridium General Recommendation)** window appears, where **<Recommendation ID>** is the automatically generated Recommendation ID of the new record, displaying the Meridium General Recommendation datasheet.

The Meridium General Recommendation record is <u>populated with values that are</u> stored in the source Health Indicator record and records to which it is linked.

- 3. Complete additional fields as desired.
- 4. Click OK.

The **Asset Health Manager** page returns to focus. If the Health Indicator record meets *Warning* or *Alert* status criteria, a message appears, asking if you want to acknowledge the status (change the status to *Normal*).

- 5. If you:
 - Want to <u>acknowledge the status</u>, click the **Yes** button.
 - Do not want to acknowledge the status, click the **No** button.


Creating a Recommendation Record Based Upon Multiple Health Indicators

The following instructions assume that you are viewing the <u>Asset Health Manager page</u> for the Equipment record whose associated Health Indicator records you want to use as the basis for a Meridium General Recommendation record.

To create a Meridium General Recommendation record based upon the status of multiple Health Indicator records:

1. In the **Health Indicator Explorer** pane, select the Equipment record whose associated Health Indicator records you want to use as the basis for a Meridium General Recommendation record.


For example, the node representing the Equipment record *0002-049* ~ *000000000001026082* ~ *LOOP SYSTEMS* ~ *Miscellaneous Instrument* ~ *INS MIS MIS* is selected in the following image.



2. On the **Summary** tab, select the Health Indicator records that you want to use as the basis for the Meridium General Recommendation record.

For example, a red outline has been added to the following image to highlight the selection of the following Health Indicator records:

- % of Key Fields at Work Order Close
- % of Recommendations Implemented



3. Click the 🍢 button.

The **<Recommendation ID> (new Meridium General Recommendation)** window appears, where **<Recommendation ID>** is the automatically generated Recommendation ID of the new record, displaying the Meridium General Recommendation datasheet.

-+	sheet Meridium Coneral Rec	ammondation 🔲 🔊 🕒 📭 🗸 🖧 🔍 🔍 🖉	Operatio
		ommendation 🔽 🔞 🔓 🥵 🗙 🗅 🍐 😒 🐯 🧠	operatio
ene	eral Information		
_[Value(s)	
►F	Recommendation ID	REC-1128	
F	Recommendation Headline		
F	Recommendation Description	% of Key Fields at Work Order Close \sim Alarm \sim 3/1/2011 12:00:00 AM \sim 0 % of Recommendations Implemented \sim Alarm \sim 3/1/2011 12:00:00 AM \sim 70	
F	Recommendation Basis		
1	Asset ID	0000000001026082	••
E	Equipment Technical Number	0002-049	
F	Function ID	MRD-ROA-REFN-RF049-0002-049	••
F	Required Equipment Status		
E	Business Impact		
1	Target Completion Date		
1	Mandatory Date		
F	Recommendation Priority		
1	Author Name	Administrator, Meridium MIADMIN	
(Create Work Request?		
1	Work Request Reference		
1	Work Request Equipment		
1	Work Request Functional		
1	Implemented Date		

The Meridium General Recommendation record is <u>populated with values that are</u> <u>stored in the source Health Indicator record and records to which it is linked</u>.

- 4. Complete additional fields as desired.
- 5. Click **OK**.

The **Asset Health Manager** page returns to focus. If the Health Indicator record meets *Warning* or *Alert* status criteria, a message appears, asking if you want to acknowledge the status (change the status to *Normal*).

- 6. If you:
 - Want to <u>acknowledge the status</u>, click the **Yes** button.
 - Do not want to acknowledge the status, click the **No**button.

Values Mapped to Meridium General Recommendation Records

When you create a Meridium General Recommendation record based upon a single or multiple Health Indicator records, various fields in the Meridium General Recommendation record are populated automatically by the Meridium APM System with values from records that are associated with the source Health Indicator record(s).

One additional field, Recommendation Description, is populated with a combination of values in records that are associated with the Health Indicator record(s). The following table lists the values that make up the value *Health Indicator Name> ~ <Alert Status> ~ <Current Reading Date> ~ <Current Reading>* that is populated in the Recommendation Description field.

<health Indicator Name></health 	The value in the Name field in the Health Indicator record.
<alert Status></alert 	The value in the Alert Status field in the Health Indicator record.
<current Reading Date></current 	One of the following values, depending upon the type of record that is linked to the Health Indicator record. If the Health Indicator is linked to:
	 A Measurement Location record, this value is the most recent Reading Taken Date value in the associated Reading records.
	 A KPI record, this value is the most recent Measurement Date value in the associated KPI Measurement records.
	 An Xi Tag record, this value is the most recent Time Stamp value in the associated Xi Reading records.
<current Reading></current 	One of the following values, depending upon the type of record that is linked to the Health Indicator record. If the Health Indicator is linked to:
	 A Measurement Location record, this value is the Reading Value Character or Reading Value Numeric value in the most recent associated Reading record.
	 A KPI record, this value is the Actual value in the most recent associated KPI Measurement record.
	 An Xi Tag record, this value is the Value or Value CHR value in the most recent associated Xi Reading record.

For Meridium General Recommendation records that are <u>created from *more than* one</u> <u>Health Indicator record</u>, the Recommendation Description field contains the combination of values listed above for *each* associated Health Indicator record. For example, the following image shows an example of a Meridium General Recommendation record that was created from the following Health Indicator records:

- % of Key Fields at Work Order Close
- % of Recommendations Implemented

C-1128 (new Meridium General Recommendation)					
R	REC-1128 (new	Meridium General Recommendation)			
	asheet Meridium General Reco	ommendation 🔽 😼 🚽 🔛 🥵 🗙 👘 🍪 😒 🐯 🥰	Operations :		
uen			1		
		Value(s)			
▶	Recommendation ID	REC-1128			
	Recommendation Headline				
	Recommendation Description	% of Key Fields at Work Order Close \sim Alarm \sim 3/1/2011 12:00:00 AM \sim 0 % of Recommendations Implemented \sim Alarm \sim 3/1/2011 12:00:00 AM \sim 70			
	Recommendation Basis				
	Asset ID	0000000001026082			
	Equipment Technical Number	0002-049			
	Function ID	MRD-ROA-REFN-RF049-0002-049			
	Required Equipment Status				
	Business Impact				
	Target Completion Date				
	Mandatory Date				
	Recommendation Priority				
	Author Name	Administrator, Meridium MIADMIN			
	Create Work Request?				
	Work Request Reference				
	Work Request Equipment				
	Work Request Functional				
	Implemented Date				
		ОК	Cancel		

Viewing Existing Recommendation Records

If an Equipment record that you are working with on the **Asset Health Manager** page is linked to Recommendation records, you can view those records on the **Recommendations** tab.

To view Recommendation records that are linked to the Equipment record:

- 1. In the <u>Health Indicator Explorer pane</u>, select the Equipment node.
- 2. Select the **Recommendations** tab.

The results of the **Recommendations** query that is stored in the Catalog folder \\Public\Meridium\Modules\AHI are displayed in a grid on the <u>Recommendations</u> <u>tab</u>.

Activating an Inactive Policy Instance

The following instructions assume that there is at least one policy instance associated with the Equipment record that you are evaluating on the **Asset Health Manager** page.

To activate a policy instance:

- 1. On the **Asset Health Manager** page, in the **Health Indicator Explorer** pane, select the Equipment node.
- 2. Select the **Policies** tab.

The policy instances that include that Equipment record are displayed in a grid.

3. In the results grid, in the row representing the policy instance that you want to activate, select the **Active** cell.

The **Activate** button appears, as shown in the following image.

Sur	mmary Policies Reco	mmendations				
	Instance ID	Policy	Active		Last Executed	Message
	Instance 1	<u>Xi taq 2</u>	True			
	Instance 2	<u>Xi taq 2</u>	True			
I	Instance 3	<u>Xi taq 2</u>	False	Activate		
_						

4. Click the **Activate** button.

The policy instance is activated, and the value in the **Active** cell changes to *True*.

Deleting a Health Indicator Record

To delete a Health Indicator record:

- 1. On the <u>Asset Health Manager page</u>, in the Health Indicator Explorer pane, select the Health Indicator node representing the record that you want to delete.
- 2. Below the **Health Indicator Explorer** pane, click the **Delete** button.

A message appears, asking if you are sure that you want to delete the record.

3. Click the **Yes** button.

The Health Indicator record is deleted.

About Modifying Limit Values in Health Indicator Records

When you create Health Indicator records via the Policy Manager module, you can modify the limit values in these Health Indicator records via AHM. Specifically, you can modify the following values in these Health Indicator records via AHM:

- Lower Level 1 Alert
- Lower Level 2 Alert
- Lower Level 3 Alert
- Upper Level 1 Alert
- Upper Level 2 Alert
- Upper Level 3 Alert

You may want to do this if conditions have changed since you created the policy (whose execution resulted in the creation of the Health Indicator record) and defined the limit values for the Health Indicator record (via the Policy Manager module). The following instructions assume that you have <u>accessed the Asset Health Manager page</u> for the Equipment or Functional Location record that is linked to the Health Indicator record that was created via Policy Manager whose limit values you want to modify.

To modify the limit values in a Health Indicator record created via Policy Manager:

1. In the **Health Indicator Explorer** pane, select the Health Indicator record whose limit values you want to modify.

In the following image, the Health Indicator record named *Pump Health Index* is selected in the **Health Indicator Explorer** pane.

Asset Health Manager - ~	PUMP 1~ HXST 152
	Current Health Indicator is out of sync with latest data. Details Trend Stored Data Source Name Pump Health Index Description Composite of Flow Rate, Pressure, Lubrication, General Operation, and Vibration for Pump 1 Limit Values Upper Level 3 140 Upper Level 2 125 Upper Level 1 115 Lower Level 1 90 Lower Level 2 80 Lower Level 3 70
Filters Add Delete	

2. In the Limit Values workspace, in the <u>text box that corresponds with the field in</u> <u>the Health Indicator record</u> whose value you want to modify, type the limit value that you want to use.

The Health Indicator values are updated automatically when you navigate away from the **Asset Health Manager** page.

AHM Catalog Folder Structure

The following table lists the query that is stored in the Catalog location \\Public\Meridium\Modules\AHI. The query name is listed in the table. The query name and caption are the same.

Query	Behavior and Usage
Recommendations	Returns all Recommendation records <i>except</i> RCM FMEA Recommendation and RBI Recommendations records that are linked to a specific Equipment record. The results of this query are displayed on the on the Recommendations tab in the on the <u>Asset</u> <u>Health Manager page</u> .

Dashboards Folder

The following table lists the dashboard that is stored in the Catalog location \\Public\Meridium\Modules\AHM\Dashboards. The dashboard name is listed in the table. The dashboard name and caption are the same.

Dashboard	Behavior and Usage
AHM Start	Displays the baseline Asset Health Manager dashboard on the Dash-
Page	board page, which serves as the start page for the AHM module.

Queries Folder

The following table lists the query that is stored in the Catalog location \\Public\Meridium\Module\AHI\Queries. The query name is listed in the table. The query name and caption are the same. The Queries folder also contains one subfolder, <u>Dashboard Queries</u>.

Query	Behavior and Usage
Policy Integration	Returns all Policy records that are associated with a policy instance that includes a specific Equipment record. The results of this query are displayed on the Policies tab on the Asset Health Manager page.

Dashboard Queries Folder

The following table lists the queries that are stored in the following Catalog location \\Public\Meridium\Module\AHI\Queries\Dashboard Queries. The queries are listed in the table by name. The query name and caption are the same unless otherwise noted.

Query	Behavior and Usage
AHM Assets in Alert	Returns all Health Indicator records whose Alert Level field contains the value <i>1</i> or <i>2</i> . This query contains prompts on:
	 The Superior Function Location field in the Func- tional Location record that is linked to the Equip- ment record that is associated with the Health Indicator record.
	 The Last Reading Date field in the Health Indicator record.
	The results of this query are displayed in the <u>Health Indic</u> - ators in Alert section on the <u>AHM Start Page</u> .
AHM Parameters Query	Used to build the <u>Health Indicator Filter section</u> on the <u>AHM Start Page</u> .

Event Mapping

Event Mapping records store information that determine the values in source event families that are displayed on the <u>Events tab</u> on the <u>Asset Health Manager page</u>. Field descriptions are not provided for this family because you will not view or modify data in records in this family via the datasheet. Rather, you will view and modify data in these records via <u>the Event Mappings window</u>.

Health Indicator

Health Indicator records store information for individual factors that are used to determine the health of equipment. The following table provides an alphabetical list and description of the fields that exist in the Health Indicator family. The information in the table reflects the baseline state and behavior of these fields. This list is not comprehensive.

Field	Data Type	Description	Behavior and Usage
Acknowledged	Logical	Indicates whether or not the status of the Health Indicator has been <u>acknowledged</u> .	 When this field is set to: <i>True</i>, the status of the Health Indicator record has been acknowledged. <i>False</i>, the status of the Health Indicator record has not been acknowledged.
Alert Level	Number	Indicates the status of the Health Indic- ator record.	 If the Meridi- um.AHI.Service.exe.config file has been configured properly, this value is populated auto- matically by the AHM Service with one of the following values: 0 (zero): Indicates that the Health Indicator record meets the Normal status criteria. 1: Indicates that the Health Indicator record meets the Warning status criteria. 2: Indicates that the Health Indicator record meets the Alert status cri- teria. This field is not displayed on the baseline Health Indicator data- sheet.
Description	Character	A description of the Health Indicator record.	This field is displayed on the Main tab of the Health Indicator datasheet.

Field	Data Type	Description	Behavior and Usage
Name	Character	The record ID of the Health Indicator record.	This value must be unique. This field is displayed on the Main tab of the Health Indicator data- sheet.
ML Type	Character	For Health Indicator records whose primary source records are Meas- urement Location records, indicates the type of data stored in the asso- ciated secondary source records (Read- ing records).	On the datasheet, this field appears as a list labeled ML Type and contains the following values: • Character • Numeric

Health Indicator Mapping

Health Indicator Mapping records are used to determine how values will be mapped from primary source records to the Health Indicator records that they are used to create. The following table provides an alphabetical list and description of the fields that exist in the Health Indicator Mapping family. The information in the table reflects the baseline state and behavior of these fields. This list is not comprehensive.

Field	Data Type	Description	Behavior and Usage
Description	Character	The purpose of the Health Indicator Mapping record.	This value is not used when map- ping data from primary source records to Health Indicator records.
Family ID	Character	The family caption of the primary source family.	The list in this field contains all families that are successors to the Health Indic- ator family through the Health Indicator Has Source rela- tionship.
Mapping Type	Character	The type of data that will be eval- uated in the primary source record to determine the <u>status of the Health</u> <u>Indicator record</u> .	The list in this field contains the values <i>Char-</i> <i>acter</i> and <i>Numeric.</i>
Reading Family ID	Character	The secondary source family that con- tains the value that the Meridium APM rule logic will use to determine the status of the Health Indicator record.	The list in this field contains all families that are successors to the primary source family through any rela- tionship.

Field	Data Type	Description	Behavior and Usage
List of Val- ues Field	Character	The field in the primary source family whose values can be entered into sec- ondary source records.	The list in this field contains fields that are
		For example, Measurement Location records (primary source records) can accept either numeric of character val- ues. If they are configured to accept character values, the Allowable Val- ues field in the Measurement Loca- tion record stores values that can be entered in the Reading records (sec- ondary source records) to which it is linked.	stored in primary source records.
Source Name Field	Character	The field in the primary source family whose value will be mapped to the Name field in the Health Indicator record that is created.	The list in this field contains fields that are stored in primary source records.
Reading Date Field	Character	The field in the secondary source fam- ily that contains the value that the Meridium APM rule logic will use to present information on the Asset Health Manager page for a Health Indicator record that is created from the associated primary source record.	The list in this field contains fields that are stored in sec- ondary source records.
Reading Value Field	Character	The field in the secondary source fam- ily that contains the value that the Meridium APM rule logic will use to determine the status of the Health Indicator record.	The list in this field contains fields that are stored in sec- ondary source records.
Target Field	Character	This field is not currently used.	N/A

Field	Data Type	Description	Behavior and Usage
Asset to Source Rela- tionship Family ID	Character	The relationship family used to link the Equipment record to the primary source record.	The list in this field contains all Relationship families delivered in the baseline data- base.
Reading UOM Field	Character	The unit of measure that is asso- ciated with the secondary source record.	The list in this field contains fields that are stored in sec- ondary source records.

Event Mappings Overview

Event Mappings allow you to view data about multiple events for a single piece of equipment or location on the <u>Events tab</u> on the <u>Asset Health Manager page</u>. This concept is best illustrated through an example.

Suppose that you use AHM to analyze an Equipment record that is linked to the following records that store information about events that took place for that piece of equipment:

- A Work History record that identifies a repair that took place.
- An Inspection record that identifies a visual inspection that was performed.

In this case, on the **Events** tab on the **Asset Health Manager** page, you can view data that is stored in *both* of these records so that you can monitor the condition of the piece of equipment or look for trends in the events.

Note: Throughout this documentation, we refer to records that represent events that took place for a piece of equipment or location as *source event records*.

Event Mappings are used to specify the values in source event records (e.g., Work History records) and other values that should be displayed on the **Events** tab on the **Asset Health Manager** page. Specifically, each Event Mapping consists of the following items:

- One Event Mapping record.
- At least one event severity.
- Multiple event severity mappings (optional).

Event Mapping records specify the values in source event records that should be displayed on the **Events** tab. The baseline Meridium APM database contains Event Mapping records that identify values in the following source event families:

- Bundle Inspection
- Full Inspection
- General Inspection
- Inspection
- Policy Event
- Pressure Test Inspection
- Production Event
- All Calibration subfamilies
- All Checklists subfamilies
- Work History

An *event severity* specifies the severity that is associated with the event (i.e., the gravity or seriousness of the events) that is represented by a record belonging to the family that

is identified by that Event Mapping record. For example, the severity of a routine inspection on a piece of equipment or a preventive maintenance activity would be different from the severity of a repair that took place after a failure. The default event severity for *every* baseline Event Mapping record is *Information*. You can define additional event severities (*Warning* and *Alarm*) when you create event severity mappings. Event severities are *not* stored in the Event Mapping record or any record belonging to an entity family in the Meridium APM database.

Event severity mappings identify the specific values in source event records that correspond with a particular event severity. Each Event Mapping can have *up to* three event severity mappings, one for each of the following event severities: *Information, Warning*, and *Alarm*. If an Event Mapping does not contain *any* event severity mappings, then all source event records that belong to the family that is represented by the corresponding Event Mapping record will be assigned the *same* event severity, which is identified by the default event severity. For example, in the baseline database, all Inspection records that are used in AHM will be assigned the same event severity (*Information*), which is identified by the default event severity associated with the Event Mapping record with the Record ID *Inspection*. In the baseline Meridium APM database, event severity mappings are defined *only* for the Event Mapping records that are associated with the Policy Event family and the Work History family. Event severity mappings are also *not* stored in the Event Mapping record or any record belonging to an entity family in the Meridium APM database.

While both an Event Mapping record and default event severity are *required* in order to view event data in a source event record on the **Events** tab, event severity mappings are *not* required to view event data in a source event family on the **Events** tab.

Accessing the Event Mappings Window

Super Users and members of the MI AHM Administrator Security Group can access the **Event Mappings** window via the **Asset Health Manager** page.

To access the Event Mappings window:

- 1. On the Asset Health Manager page, select the Events tab.
- 2. On the **Events** tab, click the <u>s</u> button to expand the Filter section.

The Filter section expands.

		¥
Severity	Type Select All	Date Range
🗷 🔕 Alert	API 510 External Checklist	From 05/07/2012 10:44
🗷 🗛 Warning	API 510 Internal Checklist	To
👿 🗊 Information	API 510 Internal Exchanger Checklist	05/07/2013 10:44
	API 570 External Checklist	Get
	🗹 API 653 External Checklist	
	☑ API 653 Internal Checklist	
	Calibration, Analog	
	Calibration, Analyzer Multi-Component	
	Calibration, Analyzer Single Component	
	☑ Calibration, Discrete	Ŧ

3. In the Filter section, click the 🙋 button.

The **Event Mappings** window appears, and the first family is selected in the <u>Source</u> Event Family pane by default.

Event Mappings		×
AddRemoveAPI 510 External ChecklistAPI 510 Internal ChecklistAPI 510 Internal ExchanAPI 570 External ChecklistAPI 653 External ChecklistAPI 653 Internal ChecklistBundle InspectionCalibration, AnalogCalibration, Analyzer MulCalibration, Analyzer SinCalibration, Functional TCalibration, Functional TCalibration, Weight ScaleExternal PRD ChecklistFull InspectionGeneral InspectionInspectionPolicy EventPressure Test InspectionProduction EventWork History	*Mapped Family API 510 External Check	Cancel Save
	*Event Relationship *Start Time Field End Time Field Name Field Description Field Has Duration Field Severity Field *Default Severity Information	Has Inspections Completion Date (select) Inspection Reference Scope (select) (select) (select) (select)
	*Event Severity (Add Mapping)	*Mapped Severity Code

Aspects of the Event Mappings Window

You can use the **Event Mappings** window to create, modify, or delete:

- Event Mapping records.
- The default event severity.
- Event severity mappings.

The **Event Mappings** window contains the following panes:

- <u>The left pane</u>: Displays the caption of each source event family for which Event Mappings have been created.
- <u>The right pane</u>: Displays grids and lists that are used to define the Event Mappings for the family that is selected in the left pane.

Source Event Family Pane

On the left side of the **Event Mappings** window, an unlabeled pane appears that displays the caption of each source event family for which an Event Mappings exists. Throughout the documentation, we refer to this unlabeled pane as the *Source Event Family pane*.

The following image shows an example of what the Source Event Family pane looks like. A red outline has been added to the image to highlight the Source Event Family pane.

Event Mappings				×
Add Remove			Cancel	Save
API 510 External Checklist API 510 Internal Checklist API 510 Internal Exchan	*Mapped Family API 510 External Checklist			
API 570 External Checklist	Event Field	Mapped Field		
API 653 External Checklist API 653 Internal Checklist	*Event Relationship	Has Inspections		<u> </u>
Bundle Inspection	*Start Time Field	Completion Date		-
Calibration, Analog Calibration, Analyzer Mul	End Time Field	(select)		
Calibration, Analyzer Sin	Name Field	Inspection Reference		-
Calibration, Discrete	Description Field	Scope		-
Calibration, Functional T Calibration, Weight Scale	Has Duration Field	(select)		
External PRD Checklist	Severity Field	(select)		
Full Inspection General Inspection Inspection Policy Event Pressure Test Inspection	*Default Severity Information 💌			
	*Event Severity	*Mapped Severity C	ode	
Production Event	(Add Mapping)			
Work History				

The captions of the families for which Event Mappings exist are displayed in the Source Event Family pane if the license for the associated module is active *and* you have View privileges for the family. For example, a baseline Event Mappings exists for the Production Event family. If the Production Loss Accounting license is active and you have View privileges to the Production Event family, *Production Event* will be listed in the Source Event Family pane. If the Production Loss Accounting license is *not* active or you do not have View privileges to the Production Event family, *Production Event* will *not* be listed in this pane.

The following buttons are displayed above the Source Event Family pane:

- Add: Adds the entry (*new mapping*) at the top of the Source Event Family pane and refreshes the Mappings pane to display empty lists that you can use to <u>create</u> <u>a new Event Mapping</u>.
- **Remove:** After displaying a confirmation message, deletes the selected entry from the Source Event Family pane and deletes the Event Mapping associated with the selected family.

Mappings Pane

On the right side of the **Event Mappings** window, an unlabeled pane appears that contains items that are used to define the Event Mapping for the family that is selected in <u>Source Event Family pane</u>. Throughout the documentation, we refer to this unlabeled pane as the *Mappings pane*.

The following image shows an example of the Mappings pane when the family *API 510 External Checklist* is selected in the Source Event Family pane. A red outline has been added to the image to highlight the Mappings pane.

The Mappings pane contains the following items:

• **Mapped Family list:** Contains the caption of every entity family in the database for which an Event Mapping does *not* exist *and* for which you have View privileges.

The caption of the source event family that is selected in the Source Event Family pane is selected by default. If you are <u>creating a new Event Mapping</u>, the value *(select)* is selected by default. You must select a value in this list in order to save the Event Mapping.

• First Grid: Displays rows that are used to specify the source event family fields whose values will be displayed in the grid on the Events tab on the Asset Health Manager page. In the first grid, one row is displayed for each column that appears in the grid on the Events tab. In other words, each *row* in the first grid represents a *column* in the grid on the Events tab. Throughout this documentation, we refer to the rows by the value in the Event Field cell in these rows.

For example, the following image illustrates the *Start Time Field* row.

```
*Start Time Field Completion Date
```

The following table identifies each row in the first grid, the columns to which they correspond (in the grid on the **Events** tab), and the values that are available in the **Mapped Field** column.

Ŧ

Row	Corresponding Column	Mapped Field List
Start Time Field	Start Time	Every date field in the source event family.
End Time Field	End Time	Every date field in the source event family.
Name Field	Name	Every field in the source event family <i>except</i> date fields.
Description Field	Description	Every field in the source event family <i>except</i> date fields.
Severity Field	Severity	Every field in the source event family <i>except</i> date fields.

Notice that the **Event Relationship** row and the **Has Duration** row are excluded from this table. These rows are unique to the first grid in that they do *not* represent columns in the grid on the **Events** tab. Instead, these rows serve the following functions:

Event Relationship: Specifies the relationship family that links the piece of equipment or location to the source event record. The Mapped Field list in this row displays every relationship family for which the source event family is a successor in the relationship definition.

 Has Duration: Specifies whether or not the source event record represents an event that has duration. The Mapped Field list in this row contains every logical field in the source event family.

Note: You must select an *Event Relationship* and *Start Time Field* in order to save the Event Mapping.

- **Default Severity list:** Specifies the severity that is associated with the source event family by default. The default severity determines the icon that is displayed in the grid on the Events tab for events of this type (i.e., for records in the source event family). This list contains the following values:
 - Information: Indicates that records in the source event family represent routine activities conducted for the piece of equipment or location. For example, if the source event record represents a routine inspection on the piece of equipment, you might select *Information* in this list. This value is selected in this list by default.
 - Warning: Indicates that records in the source event family represent events that convey a low-risk warning about the piece of equipment or location. For example, if the source event record represents activity that indicates that the piece of equipment is nearing its end of life, you might select *Warning* in this list.
 - Alert: Indicates that records in the source event family represent events that convey a high-risk warning about the piece of equipment or location. For example, if the source event record represents activity that indicates that the piece of equipment is about to fail, you might select *Alert* in this list.
- **Second Grid:** Displays one row for each event severity mapping that you have defined. The grid contains the following columns:
 - Event Severity: Contains a list in which one of following values is selected that corresponds with the event severity for which you have defined a mapping:
 - Information
 - Warning
 - Alert

If you have not defined any event severity mappings, this column contains the entry *(Add Mapping)*, which appears as a hyperlink that you can click to add a row to the grid.

Mapped Severity Code: Contains text boxes in which you should type the value that is stored in the field in the source event record that is mapped to the Severity Field ID field in the Event Mapping record that corresponds with the severity in that row. When you click (Add Mapping) in the Event Severity column to define an event severity mapping, you must type a value in the text box in the Mapped Severity Code column in order to save the Event Mapping. This value appears to the right of the icon in the Severity column in the grid on the Events tab.

For example, in the baseline Meridium APM database, an Event Mapping record specifies that the value in the Severity field in the Policy Event family is mapped to the Severity Field ID field in the associated Event Mapping record. Continuing with this example, in the baseline Meridium APM database, the event severity mappings shown in the following image are defined for the Policy Event family.

*Event Severity		*Mapped Severity Code	
Information	•	INF	×
Warning	-	WRN	X
Alert	•	ALT	X

Based upon the event severity mappings shown in the preceding image, when the Severity field in a Policy Event record contains the value *INF*, the Information icon and the value that is specified for events with a severity of *Information* (i.e., *INF*) is displayed on the **Events** tab, as illustrated in the following image.

Severity	Name	Description	Туре	Start	End
1 INF	POLICY EVENT - 1			5/1/2013 1:09:	5/1/2013 1:09:

The following buttons are displayed above the Mappings pane:

- **Cancel:** Displays a confirmation message, confirming that you do not want to save the Event Mapping.
- Save: Closes the Event Mappings window and saves the Event Mapping.

Accessing the Event Mappings Page

Super Users and members of the MI AHM Administrator Security Group can access the **Event Mappings** page via Record Manager.

To access the Event Mappings page:

- 1. Open an Event Mapping record in Record Manager.
- 2. Click the hyperlink that appears about the Event Mapping datasheet.

The **Event Mapping** page appears.

le <u>E</u> dit <u>G</u> o⊤o <u>T</u> ools <u>H</u> elp)Back - ⊗ Forward - ⊘ Refr		rch 🚞 Catalog 🔞 Query 🔹 🛅 Report 🕶 🕼 Graph 🗸 🌢	🖁 Dataset 🕶 🖬 Dashboard 🕶
vent Mappings			
Add Remove			Cancel Save
API 510 External Checklist API 510 Internal Checklist API 510 Internal Exchan	*Mapped Family Full Inspection		
API 510 Internal Exchan	Event Field	Mapped Field	
API 653 External Checklist	*Event Relationship	Has Inspections	-
API 653 Internal Checklist Bundle Inspection	*Start Time Field	Commencement Date	
Calibration, Analog	End Time Field	Completion Date	•
Calibration, Analyzer Mul	Name Field	Inspection Reference	•
Calibration, Analyzer Sin Calibration, Discrete	Description Field	Scope	•
Calibration, Functional T	Has Duration Field	(select)	•
Calibration, Weight Scale External PRD Checklist	Severity Field	(select)	
Full Inspection General Inspection Inspection Policy Event	*Default Severity Information		
Pressure Test Inspection	*Event Severity	*Mapped Severity Code	
Production Event	(Add Mapping)		
Work History			

The source event family associated with Event Mapping record for which you accessed the **Event Mapping** page is selected in the <u>Source Event Family pane</u>, and the <u>Mappings pane</u> displays lists whose selections correspond with values in the Event Mapping record.

Aspects of the Event Mappings Page

The **Event Mappings** page contains all of the same items that are displayed on the **Event** <u>Mappings window</u>. The **Event Mappings** page does *not* contain any task menus.

Because the Meridium APM Asset Health Manager Best Practice assumes that you will use the <u>Event Mappings window</u> to create, modify, and delete Event Mappings, and because the functionality of the **Event Mappings** page is the same as the **Event Mappings** window, no further documentation is provided for the **Event Mappings** page.

Creating New Event Mapping Records

Super Users and members of the MI AHM Administrator Security Group can create Event Mapping records to specify the values in source event families that should be displayed on the **Events** tab on the **Asset Health Manager** page. Additionally, these users can specify the severity that is associated with an event by default. Although this value (the default event severity) is not stored in the Event Mapping record or any record in the Meridium APM database, we provide instructions on specifying this value at the time that you create an Event Mapping record because you will use the same interface to perform both of these actions (creating an Event Mapping record and specifying the default event severity), and because an event severity cannot exist without an associated Event Mapping record.

Event Mapping records can be created using the <u>Event Mappings page</u> or the <u>Event Mappings window</u>. The Meridium APM Asset Health Manager Best Practice and these instructions assume that you will create Event Mapping records via the **Event Mappings** window.

To create a new Event Mapping record:

- 1. Access the Event Mappings window.
- 2. Above the Source Event Family pane, click the **Add** button.

The entry *(new mapping)* appears at the top of the Source Event Family pane, the Mappings pane displays lists in which values are not selected, and validation messages for required fields are displayed at the top of the window.

Event Mappings		×
◆ 3 of 3 → (<u>View D</u>	etails) The Start Time field is require	ed.
Add Remove		Cancel Save
(new mapping) API 510 External Checklist API 510 Internal Checklist	*Mapped Family (select)	
API 510 Internal Checklist API 510 Internal Exchan	Event Field	Mapped Field
API 570 External Checklist	*Event Relationship	(select)
API 653 External Checklist API 653 Internal Checklist	*Start Time Field	(select)
Bundle Inspection	End Time Field	(select)
Calibration, Analog Calibration, Analyzer Mul	Name Field	(select)
Calibration, Analyzer Sin	Description Field	(select)
Calibration, Discrete	Has Duration Field	(select)
Calibration, Functional T Calibration, Weight Scale	Severity Field	(select)
External PRD Checklist Full Inspection General Inspection Inspection	*Default Severity Information 💌	
Policy Event	*Event Severity *Ma	apped Severity Code
Pressure Test Inspection	(Add Mapping)	
Production Event Work History		
,		

- 3. In the Mappings pane, in the <u>Mapped Family list</u>, select the source event family for which you want to create an Event Mapping record.
- 4. In the <u>first grid</u>, select the fields in the source event family that you want to be mapped to fields in the Event Mapping record.
- 5. In the <u>Default Severity list</u>, select the value that corresponds with the severity that is associated with the source event record by default.
- 6. Optionally create event severity mappings for the Event Mapping.
- 7. Click the **Save** button at the top of the window.

The Event Mapping record is saved. Event data for the source event family, the default event severity, and any event severity mappings that you have defined will now be displayed on the <u>Events tab</u> on the <u>Asset Health Indicator page</u> when an Equipment or Functional Location record that is linked to that source event family is selected in the **Health Indicator Explorer** pane. Additionally, a check box labeled

with the source event family caption will now be displayed in the <u>Filter section</u> on the **Events** tab.

Modifying Existing Event Mappings

Super Users and members of the MI AHM Administrator Security Group can modify existing Event Mapping records to modify the values that are displayed on the <u>Events</u> <u>tab</u> on the **Asset Health Manager** page for a source event family. Additionally, these users can modify the severity that is associated with an event by default. Although this value (the default event severity) is not stored in the Event Mapping record or any record belonging to an entity family in the Meridium APM database, we provide instructions on modifying this value at the time that you modify an Event Mapping record because you will use the same interface to perform both of these actions (modifying an Event Mapping record and modifying the default event severity), and because an event severity cannot exist without an associated Event Mapping record.

Event Mapping records can be modified using the <u>Event Mappings page</u> or the <u>Event</u> <u>Mappings window</u>. The Meridium APM Asset Health Manager Best Practice and these instructions assume that you will modify Event Mapping records via the **Event Mappings** window.

To modify an existing Event Mapping record:

- 1. Access the Event Mappings window.
- 2. In the Source Event Family pane, select the source event family whose associated Event Mapping record you want to modify.

The Mappings pane is refreshed to display the selections for the family selected in the Source Event Family pane. For example, in the following image, *Bundle Inspection* is selected in the Source Event Family pane.

Event Mappings		×
Add Remove		Cancel Save
API 510 External Checklist API 510 Internal Checklist API 510 Internal Exchan API 570 External Checklist API 653 External Checklist	*Mapped Family Bundle Inspection Event Field *Event	Mapped Field Has Inspections T
API 653 Internal Checklist Bundle Inspection Calibration, Analog	Relationship *Start Time Field End Time Field	Commencement Date
Calibration, Analyzer Mul Calibration, Analyzer Sin Calibration, Discrete Calibration, Functional T Calibration, Weight Scale External PRD Checklist Full Inspection General Inspection Inspection Policy Event	Name Field Description Field	Completion Date Inspection Reference Scope
	Has Duration Field Severity Field	(select) <pre>(select)</pre>
	*Default Severity Information •	
Pressure Test Inspection Production Event Work History	*Event Severity (Add Mapping)	*Mapped Severity Code

- 3. If you want to modify the:
 - Fields in source event records that are mapped to fields in the Event Mapping record, in the Mappings pane, in the <u>first grid</u>, modify the selections in the associated lists.
 - Severity that is associated with the source event record by default, in the Mappings pane, modify the selection in the <u>Default Severity list</u>.
- 4. Optionally modify the associated event severity mappings.
- 5. Click the **Save** button at the top of the window.

Your modifications to the Event Mapping record are saved. Event data for the source event family, the default event severity, and any event severity mappings that you have defined will now be displayed on the <u>Events tab</u> on the <u>Asset Health</u> <u>Indicator page</u> when an Equipment or Functional Location record that is linked to the source event family is selected in the **Health Indicator Explorer** pane.

Deleting Event Mapping Records

Super Users and members of the MI AHM Administrator Security Group can delete existing Event Mapping records that are associated with source event families whose values you do *not* want displayed in the grid on the <u>Events tab</u> on the Asset Health Manager page. When you delete an Event Mapping record, the associated event severities and event severity mappings are also deleted because event severities and event severity mappings cannot exist without an associated Event Mapping record.

Event Mapping records can be deleted using the <u>Event Mappings page</u> or the <u>Event Mappings window</u>. The Meridium APM Asset Health Manager Best Practice and these instructions assume that you will delete Event Mapping records via the **Event Mappings** window.

To delete an Event Mapping record:

- 1. Access the Event Mappings window.
- 2. In the Source Event Family pane, select the source event family whose associated Event Mapping record you want to delete. For example, in the following image, *Bundle Inspection* is selected in the Source Event Family pane.

Event Mappings		×
Add Remove		Cancel Save
API 510 External Checklist API 510 Internal Checklist API 510 Internal Exchan API 570 External Checklist API 653 External Checklist	*Mapped Family Bundle Inspection Event Field *Event Relationship	Mapped Field Has Inspections T
API 653 Internal Checklist Bundle Inspection Calibration, Analog Calibration, Analyzer Mul Calibration, Analyzer Sin Calibration, Discrete Calibration, Functional T Calibration, Weight Scale External PRD Checklist Full Inspection General Inspection Inspection Policy Event Pressure Test Inspection Production Event Work History	Relationship *Start Time Field End Time Field Name Field Description Field Has Duration Field Severity Field *Default Severity Information *Event Severity (Add Mapping)	Commencement Date Completion Date Inspection Reference Scope (select) (select) *Mapped Severity Code

3. At the top of the Source Event Family pane, click the **Remove** button.

A confirmation message appears, asking if you are sure you want to delete the Event Mapping record.

4. Click OK.

The Event Mapping record is deleted, and the corresponding value is removed from the Source Event Family pane.

Event Mappings		×
Add Remove		Cancel Save
API 510 External Checklist API 510 Internal Checklist API 510 Internal Exchan API 570 External Checklist	*Mapped Family API 510 External Check	klist 🔹
API 653 External Checklist	*Event Relationship	Has Inspections
API 653 Internal Checklist Calibration, Analog	*Start Time Field	Completion Date
Calibration, Analyzer Mul	End Time Field	(select)
Calibration, Analyzer Sin Calibration, Discrete	Name Field	Inspection Reference
Calibration, Functional T	Description Field	Scope
Calibration, Weight Scale External PRD Checklist	Has Duration Field Severity Field	(select)
Full Inspection General Inspection Inspection Policy Event Pressure Test Inspection	*Default Severity Information	(select)
Production Event	*Event Severity	*Mapped Severity Code
Work History	(Add Mapping)	

Additionally, the associated event severities and event severity mappings are deleted, and the corresponding check box in the <u>Filter section</u> on the <u>Events tab</u> is removed.

Calibration Subfamilies

The table in this topic lists the fields in Calibration subfamilies that are mapped to fields in their associated Event Mapping record and the:

- Column in the grid on the **Events** tab that corresponds with each field.
- List in the <u>Mappings pane</u> on the <u>Event Mappings window</u> that corresponds with each field.

Note: The following table lists Calibration subfamily field captions, some of which may differ from the datasheet captions for these fields.

Mapped Calibration subfamily field	Column in grid on the Event tab	List in the Mappings pane on the Event Map- pings win- dow
This field does not have a mapped Calibration field. This field displays the caption of the relationship family that links the Calibration subfamily to the Equipment or Func- tional Location family (i.e., Has Calibration).	N/A	Event Rela- tionship
Event End Date	End	End Time Field
This field does not have a mapped Calibration field. This field displays the family caption of the associated Cal- ibration subfamily.	Туре	Mapped Family
Event Long Description	Description	Description Field
 This field does not have a mapped Calibration field. The Name column in the grid on the Events tab displays the Record ID of the Calibration record by default. You can modify the Event Mapping record if you want to specify a mapped field. 	Name	Name Field
This field does not have a mapped Calibration field. The Severity column in the gird on the Events tab displays an icon that corresponds with an event severity of <i>Information</i> by default. You can <u>modify the Event Mapping record</u> if you want to	Severity	Severity Field
icon that corresponds with an event severity of <i>Inform-</i> <i>ation</i> by default.	Severity	Severity Fig

Mapped Calibration subfamily field	Column in grid on the Event tab	List in the Mappings pane on the Event Map- pings win- dow
Event Start Date	Start	Start Time Field

Inspection Families

The table in this topic lists the fields in the Inspection family and the following Inspection subfamilies that are mapped to fields in their associated Event Mapping record, the corresponding column in the grid on the <u>Events tab</u>, and the corresponding list in the <u>Mappings pane</u> on the <u>Event Mappings window</u>:

- Bundle Inspection
- Full Inspection
- General Inspection
- Pressure Test Inspection

Note: The following table lists Inspection family and subfamily field captions, some of which may differ from the datasheet captions for these fields.

Mapped Inspection family and subfamily field	Column in grid on the Event tab	List in the Mappings pane on the Event Mappings win- dow
This field does not have a mapped Inspection field. This field displays the cap- tion of the relationship fam- ily that links the Inspection family to the Equipment or Functional Location family (i.e., Has Inspections).	N/A	Event Relationship
Completion Date	End	End Time Field
This field does not have a mapped Inspection field. This field displays the fam- ily caption of the associated Inspection family.	Туре	Mapped Family
Scope	Description	Description Field
Inspection Reference	Name	Name Field

Mapped Inspection family and subfamily field	Column in grid on the Event tab	List in the Mappings pane on the Event Mappings win- dow
This field does not have a mapped Inspection field. The Severity column in the grid on the Event tab dis- plays an icon that cor- responds with an event severity of <i>Information</i> by default. You can <u>modify the Event</u> <u>Mapping record</u> if you want to specify a mapped field.	Severity	Severity Field
Commencement Date	Start	Start Time Field

Checklists Subfamilies

The table in this topic lists the fields in Checklists subfamilies that are mapped to fields in their associated Event Mapping record and the:

- Column in the grid on the **Events** tab that corresponds with each field.
- List in the <u>Mappings pane</u> on the <u>Event Mappings window</u> that corresponds with each field.

Note: The following table lists Checklists subfamily field captions, some of which may differ from the datasheet captions for these fields.

This field does not have a mapped Checklists sub- family field. This field dis- plays the caption of the relationship family that links the Checklists subfamily to the Equipment or Functional Location family (i.e., Has Inspections).	N/A	Event Relationship
Scope	Description	Description
This field does not have a mapped Checklists sub- family field. This field dis- plays the family caption of the associated Checklists subfamily.	End	End Time Field
This field does not have a mapped Checklists sub- family field. This field dis- plays the family caption of the associated Checklists subfamily.	Туре	Mapped Family
Inspection Reference	Name	Name Field

This field does not have a mapped Checklists sub- family field. This field dis- plays the caption of the relationship family that links the Checklists subfamily to the Equipment or Functional Location family (i.e., Has Inspections).	N/A	Event Relationship
This field does not have a mapped Checklists sub- family field. The Severity column in the grid on the Events tab displays an icon that corresponds with an event severity of <i>Inform-</i> <i>ation</i> by default.	Severity	Severity Field
You can <u>modify the Event</u> <u>Mapping record</u> if you want to specify a mapped field.		
Completion Date	Start	Start Time Field

Policy Event Family

The table in this topic lists the fields in the Policy Event family that are mapped to fields in their associated Event Mapping record and the:

- Column in the grid on the **Events** tab that corresponds with each field.
- List in the <u>Mappings pane</u> on the <u>Event Mappings window</u> that corresponds with each field.

Note: The following table lists Policy Event field captions, some of which may differ from the datasheet captions for these fields.

Mapped Policy Event field	Column in grid on the Event tab	List in the Mappings pane on the Event Map- pings win- dow
This field does not have a mapped Policy Event field. This field displays the caption of the relationship family that links the Policy Event family to the Equipment or Func- tional Location family (i.e., Has Event).	N/A	Event Rela- tionship
Description	Description	Description
End Time	End	End Time Field
This field does not have a mapped Policy Event field. This field displays the Policy Event family caption.	Туре	Mapped Fam- ily
Name	Name	Name Field
Severity	Severity	Severity Field
Start Time	Start	Start Time Field

Production Event Family

The table in this topic lists the fields in the Production Event family that are mapped to fields in their associated Event Mapping record and the:

- Column in the grid on the **Events** tab that corresponds with each field.
- List in the <u>Mappings pane</u> on the <u>Event Mappings window</u> that corresponds with each field.

Note: The following table lists Production Event field captions, some of which may differ from the datasheet captions for these fields.

Mapped Production Event field	Column in grid on the Event tab	List in the Map- pings pane on the Event Map- pings window
This field does not have a mapped Production Event field. This field displays the caption of the relationship family that links the Pro- duction Event family to the Equipment or Functional Loca- tion family (i.e., Has Pro- duction Event).	N/A	Event Rela- tionship
Description	Description	Description
End Date	End	End Time Field
This field does not have a mapped Production Event field. This field displays the Production Event family cap- tion.	Туре	Mapped Family
Headline	Name	Name Field

Mapped Production Event field	Column in grid on the Event tab	List in the Map- pings pane on the Event Map- pings window
This field does not have a mapped Production Event field. The Severity column in the gird on the Events tab dis- plays an icon that cor- responds with an event severity of <i>Information</i> by default.	Severity	Severity Field
You can <u>modify the Event Map-</u> <u>ping record</u> if you want to spe- cify a mapped field.		
Start Date	Start	Start Time Field

Work History Family

The table in this topic lists the fields in the Work History family that are mapped to fields in their associated Event Mapping record and the:

- Column in the grid on the **Events** tab that corresponds with each field.
- List in the <u>Mappings pane</u> on the <u>Event Mappings window</u> that corresponds with each field.

Note: The following table lists Work History field captions, some of which may differ from the datasheet captions for these fields.

Mapped Work History field	Column in grid on the Event tab	List in the Mappings pane on the Event Map- pings win- dow
This field does not have a mapped Work History field. This field displays the caption of the relationship family that links the Work History family to the Equipment or Functional Location family (i.e., Has Work History).	N/A	Event Rela- tionship
Event Short Description	Description	Description
Maintenance Completion Date	End	End Time Field
This field does not have a mapped Work History field. This field displays the Work History family caption.	Туре	Mapped Family
Request Type Description	Name	Name Field
Event Type	Severity	Severity Field
Event Start Date	Start	Start Time Field

System Code Tables Used by AHM

The following table lists the System Code Tables that are used by AHM.

Table ID	Table Description	Function
MI_AHM_STATUS	Health Indicator Status	Populates the Alert Level field in Health Indicator records.
MI_AHM_TIME	AHM Search Time Range	Populates the Time Range list in the Health Indicator Filter section on the AHM Start Page .
MI_HIER_ITM_GROUP	Hierarchy Item Groups	Populates the Group Name list in Hierarchy Item Defin- ition records.

Parameters for the AHM URLs

There are two root URLs associated with Asset Health Manager (AHM): **meridi-um://Registry/AssetHealthIndicators**and**meridium://AHM**. A link constructed from the path of either URL alone will open the **AHM Start Page**. The following table lists the parameters that these URLs accept.

Parameter Name	Description	Accepted Value(s)	Notes
EntityKey	Specifies the Entity Key of the record that will appear at the root level of the Health Indic- ator Explorer pane.	The Entity Key of the desired record.	If the record that you specify is linked to any Health Indicator records, they will appear below the root node in the tree.
			<i>Both</i> root URLs asso- ciated with AHM sup- port this parameter.
EventMapping	Displays the <u>Event</u> Mappings page.	N/A	<i>Only</i> the root URL meridium://AHM accepts this para- meter.

Examples of the AHM URLs

• meridium://AHM?EntityKey=1234567

Displays the **Asset Health Manager**page, where the record with the Entity Key 1234567 is displayed at the root level of the **Health Indicator Explorer** pane. If the record that is represented by the root node in the tree is linked to Health Indicator records, those records will also appear in the tree.

• meridium://Registry/AssetHealthIndicators

Displays the **Dashboard - AHM Start Page**, which operates as the start page for AHM. From this location, you can search for an Equipment or Functional Location record in order to evaluate the health of a particular piece of equipment or view data associated with Health Indicator records currently in states of *Warning* and *Alert*.

meridium://AHM/EventMapping

Displays <u>the **Event Mappings** page</u>, which you can use to work with Event Mapping records.

Note: The Meridium APM Asset Health Manager Best Practice assumes that you will use the **Event Mappings window**, as opposed to the **Event Mappings** page, to work with Event Mapping records.

Event Mapping

A combination of the following items that determine the data that is displayed on the **Events** tab on the **Asset Health Manager** page:

- An Event Mapping record.
- At least one event severity.
- <u>Multiple event severity mappings</u> (optional).

Event Severity

The gravity or seriousness associated with an event (e.g., an inspection, a repair) that has taken place for a piece of equipment or location. For each <u>Event Mapping</u>, a default event severity must be specified.

Primary Source Record

A record that is linked as a predecessor to other records whose values are used to determine Health Indicator record statuses. In the baseline database, the following records are considered to be primary source records:

- Measurement Location records
- Xi Tag records
- KPI records
- Health Indicator records created via the Policy Manager module

Primary source records are linked to directly to Health Indicator records through the Health Indicator Has Source relationship family.

Secondary Source Record

A record whose values are used to determine Health Indicator record statuses. In the baseline database, the following records are considered to be secondary source records:

- Reading records
- Xi Reading records
- KPI Measurement records
- Health Indicator Value records

Each secondary source record is linked as a successor to a primary source record.

Source Event Record

A record representing and event that has taken place for a piece of equipment or location (e.g., an inspection, a repair) that is linked to the Equipment or Functional Location record that represents the piece of equipment or location. Data in source event records is displayed on the <u>Events tab</u> on the <u>Asset Health Manager page</u> when <u>Event</u> <u>Mappings have been defined</u> for the source event family. In the baseline Meridium APM database, the following families are considered to be source event families:

- Bundle Inspection
- Full Inspection
- General Inspection
- Inspection
- Policy Event
- Pressure Test Inspection
- Production Event
- Calibration subfamilies
- <u>Checklists subfamilies</u>
- Work History